

# DIN EN 13129:2016-12 (E)

## Railway applications - Air conditioning for main line rolling stock - Comfort parameters and type tests

---

<b>Contents</b>		<b>Page</b>
European foreword .....		5
1	Scope .....	6
2	Normative references .....	6
3	Terms and definitions .....	6
4	Compliance with the standard .....	12
5	Comfort parameters .....	13
6	Quality limits .....	13
7	Service conditions .....	14
7.1	Exterior conditions .....	14
7.1.1	Design conditions .....	14
7.1.2	Extreme conditions .....	15
7.2	Interior conditions .....	15
8	Performance of the heating and cooling installations .....	16
8.1	Preheating .....	16
8.2	Heating .....	16
8.3	Precooling .....	16
8.4	Cooling .....	16
8.5	Stand by operation .....	17
8.6	Door opening sequence .....	17
8.7	Degraded mode operation .....	17
9	Control .....	17
9.1	General .....	17
9.2	Interior temperature setting .....	17
9.3	Quality of regulation .....	18
9.3.1	General .....	18
9.3.2	Changing the interior temperature setting .....	18
9.3.3	Changing test parameter(s) .....	19
9.3.4	Stabilized conditions .....	20
10	Comfort conditions to be respected .....	22
10.1	Parameters in the comfort envelope .....	22
10.1.1	Temperatures in the comfort zones .....	22
10.1.2	Temperatures of the surfaces surrounding the comfort envelope .....	23
10.1.3	Humidity of the air .....	24
10.1.4	Air speed .....	25
10.1.5	Air quality .....	26
10.2	Parameters in the annex areas .....	28
10.3	Interior parameters in the catering service areas (galley zone) .....	29
10.4	Limits of temperature values .....	29
11	Supplementary requirements .....	30
11.1	Heat transfer coefficient .....	30

11.2	Solar factor (g) of the windows .....	30
11.3	Cleaning of air conditioning installation .....	30
12	Air movement tests .....	30
12.1	Air flow tests at standstill .....	30
12.1.1	Test conditions .....	30
12.1.2	Air flow rates .....	30
12.1.3	Visualization of the air flow direction .....	31
12.2	Air flow tests when driving .....	31
12.3	Air speed tests .....	31
12.3.1	Critical air speed .....	31
12.3.2	Measurement of air speed during the climatic tests .....	31
13	Climatic tests .....	31
13.1	General remarks .....	31
13.2	Preheating test .....	32
13.3	Precooling test .....	32
13.4	Regulation tests .....	32
13.4.1	Steady-state tests .....	32
13.4.2	Intermediate tests .....	33
13.4.3	Tests for typical daily profiles .....	33
13.5	Functionality tests .....	33
14	Supplementary tests .....	34
14.1	Determination of the heat transfer coefficient .....	34
14.1.1	Purpose of the test .....	34
14.1.2	Calculation .....	34
14.1.3	Procedure .....	34
14.2	Thermography .....	35
15	Methods of measurement - Measuring instruments .....	35
15.1	General remarks .....	35
15.2	Temperatures .....	35
15.2.1	Air temperature .....	35
15.2.2	Surface temperatures .....	35
15.3	Relative humidity .....	35
15.4	Air speed .....	35
15.5	Airflow rate .....	35
15.6	Simulated speed of the vehicle .....	35
15.7	Equivalent solar energy .....	36
15.8	Energy consumption and power rating .....	36
16	Characteristics of the test equipment .....	36
16.1	General remarks .....	36
16.2	Occupation .....	36
16.3	Temperature and uniformity of the climatic chamber .....	36
16.4	Relative humidity .....	36
16.5	Simulation of wind speed .....	36
16.6	Equivalent solar energy .....	37
17	Distribution of measuring points .....	37
17.1	Distribution of sensors in the vehicle .....	37
17.1.1	Comfort envelope temperature measuring points .....	37
17.1.2	Surface temperature measuring points .....	37
17.1.3	Supply air outlet temperature measuring points .....	38
17.1.4	Comfort envelope air speed measuring points .....	38
17.1.5	Comfort envelope relative humidity measuring points .....	38
17.2	Climatic chamber sensors distribution .....	38
	Annex A (informative) Grouping of countries in climatic zones .....	39
	Annex B (normative) Calculation method of the overall conformity level CL .....	40

<b>Annex C (normative) Tests for verification of comfort parameters .....</b>	<b>43</b>
<b>Annex D (normative) Equivalent solar energy (Simulation of solar exposure) .....</b>	<b>53</b>
<b>Annex E (normative) Location of the measuring points used for the determination of the mean interior temperature in the comfort envelope (Tim), horizontal range of the extreme interior air temperatures and the measuring point location in the local annexes .....</b>	<b>54</b>
<b>Annex F (normative) Location of the measuring points used for the determination of the vertical ranges of the extreme interior air temperatures and relative humidity across the comfort envelope .....</b>	<b>56</b>
<b>Annex G (normative) Location of the measuring points used for the determination of the variation of internal temperatures within the comfort envelope .....</b>	<b>58</b>
<b>Annex H (informative) Location of the sensors in the climatic chamber .....</b>	<b>60</b>
<b>Annex I (normative) Typical daily profiles .....</b>	<b>61</b>
<b>Annex J (normative) Heat emission per person .....</b>	<b>73</b>
<b>Annex K (informative) Abbreviations .....</b>	<b>75</b>
<b>K.1 Surface temperatures: TS__Range_Surface concerned .....</b>	<b>75</b>
<b>K.2 Airflow: V_Type of airflo .....</b>	<b>75</b>
<b>K.3 Range of temperature: T_Mode_Location .....</b>	<b>75</b>
<b>K.4 Gradients: T Type of gradient_Range_Location .....</b>	<b>76</b>
<b>K.5 Others .....</b>	<b>76</b>
<b>Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2008/57/EC .....</b>	<b>77</b>
<b>Bibliography .....</b>	<b>79</b>