

DIN EN 14750-2:2006-08 (E)

Railway applications - Air conditioning for urban and suburban rolling stock - Part 2: Type tests

Contents		Page
Foreword		4
Introduction		5
1	Scope	6
2	Normative references	6
3	Terms and definitions	6
4	Test classification	6
5	Preliminary verifications	7
6	Comfort tests	7
6.1	Air movement	7
6.1.1	General remarks	7
6.1.2	Air flow rates	7
6.1.3	Pressure differentials (visualisation)	7
6.2	Critical air speed	7
6.3	Measurement of air speeds	7
7	Climatic tests	8
7.1	General remarks	8
7.2	Preheating test	8
7.2.1	Test level TL1	8
7.2.2	Test level TL2	8
7.3	Pre-cooling test	8
7.3.1	Test level TL1	8
7.3.2	Test level TL2	8
7.4	Regulation tests	9
7.5	Tests with door open/closed	9
8	Tests at extreme exterior operating conditions	9
9	Complementary tests	9
9.1	Determination of the coefficient k	9
9.1.1	Purpose of the test	9
9.1.2	Definition	9
9.1.3	Procedure	10
9.2	Thermography	10
9.3	Noise emission	10
9.4	Vibration generation	10
10	Methods of measurement - Measuring instruments	10
10.1	General remarks	10
10.2	Temperatures	11
10.2.1	Air temperature	11
10.2.2	Surface temperatures	11
10.3	Relative humidity	11
10.4	Air speed	11

10.5	Airflow rate	11
10.6	Simulated speed of the vehicle	11
10.7	Equivalent solar load	11
10.8	Energy consumption and power rating	11
11	Characteristics of the test equipment	11
11.1	General remarks	11
11.2	Occupation	12
11.3	Equivalent solar load	12
11.3.1	Solar load calculation	12
11.3.2	Window area	12
11.3.3	Wall area	13
11.3.4	Roof area	13
12	Distribution of measuring points	13
12.1	General	13
12.2	Distribution of sensors in the vehicle	14
12.2.1	Comfort envelope temperature measurement points	14
12.2.2	Surface temperature measurement points	14
12.2.3	Supply air outlet temperature measurement points	14
12.2.4	Comfort envelope air speed measurement points	14
12.2.5	Comfort envelope relative humidity measurement points	14
12.3	Climatic chamber sensor distribution	14
Annex A (normative) Test programme for TL1		15
Annex B (normative) Test programme for TL2		17
Annex C (normative) Equivalent solar load		22
Annex D (normative) Location of the measuring points used for the determination of the mean interior temperature (T _{im}), the determination of the range of extreme interior temperatures and the relative humidity in the comfort envelopes and local annexes		23
D.1	Vehicles without articulation	23
D.2	Vehicles with articulation	24
Annex E (normative) Location of the measuring points used for the determination of surface temperatures		25
Annex F (normative) Location of sensors		26