

# ISO 5608:2012-08 (E)

## Turning and copying tool holders and cartridges for indexable inserts - Designation

---

	Page
<b>Foreword .....</b>	<b>iv</b>
<b>1      Scope .....</b>	<b>1</b>
<b>2      Explanation of the designation code .....</b>	<b>1</b>
<b>2.1    General .....</b>	<b>1</b>
<b>2.2    Letter and number symbols comprising the designation code .....</b>	<b>1</b>
<b>3      Compulsory symbols .....</b>	<b>2</b>
<b>3.1    Symbol for the holding method of the horizontally mounted insert -- Reference position (1) .....</b>	<b>2</b>
<b>3.2    Symbol for insert shape -- Reference position (2) .....</b>	<b>2</b>
<b>3.3    Symbol for tool style -- Reference position (3) .....</b>	<b>3</b>
<b>3.4    Symbol for the insert normal clearance -- Reference position (4) .....</b>	<b>5</b>
<b>3.5    Symbol for hand of tool -- Reference position 5 .....</b>	<b>5</b>
<b>3.6    Symbol for tool height -- Reference position (6) .....</b>	<b>5</b>
<b>3.7    Symbol for tool width -- Reference position (7) .....</b>	<b>6</b>
<b>3.8    Symbol for tool length -- Reference position (8) .....</b>	<b>6</b>
<b>3.9    Symbol for indexable insert size -- Reference position (9) .....</b>	<b>8</b>
<b>4      Optional symbol: symbol for special tolerances -- Reference position (10) .....</b>	<b>8</b>
<b>Annex A (informative) Relationship between designations in this International Standard and the ISO 13399 series .....</b>	<b>10</b>
<b>Bibliography .....</b>	<b>11</b>