ISO/TS 13399-401:2016-02 (E)

Cutting tool data representation and exchange - Part 401: Creation and exchange of 3D models - Converting, extending and reducing adaptive items

Contents

Page

Foreword v

Introduction vii

1 Scope 1

2 Normative references 1

3 Starting elements, coordinate systems, planes 2
3.1 General 2
3.2 Reference system (PCS -- primary coordinate system) 2
3.3 Adaptive item position 3
3.3.1 General 3
3.3.2 Prismatic adaptive position 3
3.3.3 Round adaptive position 3
3.4 Adjustment coordinate system at workpiece side 3
3.4.1 General 3
3.4.2 Designation of coordinate systems at workpiece side 3
3.4.3 Arrangement of coordinate system workpiece side 4
3.5 Mounting coordinate system 5
3.6 Planes 6

4 Design of the model 6
4.1 General 6
4.2 Necessary properties for the connection interface feature 7

5 Converter, rotationally symmetric 7
5.1 General 7
5.2 Necessary properties 8
5.3 Basic geometry 8
5.4 Connection on workpiece side 10
5.5 Rotational symmetric converter, complete 11

6 Converter, stationary 12
6.1 General 12
6.2 Necessary properties 12
6.3 Basic geometry 13
6.4 Connection on workpiece side 15
6.5 Stationary converter, complete 15

7 Extender 16
7.1 General 16
7.2 Necessary properties 16
7.3 Basic geometry 16
7.4 Connection on workpiece side 17
7.5 Extender, complete 18

8 Reducer, primary design 18
8.1 General 18
8.2 Necessary properties 19
8.3 Basic geometry 19

8.4 Connection on workpiece side 20
8.5 Reducer, primary design, complete 21

9 Reducer, reverse design 21
9.1 General 21
9.2 Necessary properties 22
9.3 Basic geometry 22
9.4 Connection on workpiece side 23
9.5 Reducer, reverse design, complete 23

10 Design of details 24
10.1 Basics for modelling 24
10.2 Contact surfaces, driving features -- Orientation 24
10.3 Chamfers and roundings 24

11 Attributes of surfaces -- Visualization of the model features 25

12 Structure of the design elements (tree of model) 25

13 Data exchange model 26

Bibliography 27