

ISO/TS 13399-401:2016-02 (E)

Cutting tool data representation and exchange - Part 401: Creation and exchange of 3D models - Converting, extending and reducing adaptive items

Contents	Page
Foreword	v
Introduction	vii
1 Scope	1
2 Normative references	1
3 Starting elements, coordinate systems, planes	2
3.1 General	2
3.2 Reference system (PCS -- primary coordinate system)	2
3.3 Adaptive item position	3
3.3.1 General	3
3.3.2 Prismatic adaptive position	3
3.3.3 Round adaptive position	3
3.4 Adjustment coordinate system at workpiece side	3
3.4.1 General	3
3.4.2 Designation of coordinate systems at workpiece side	3
3.4.3 Arrangement of coordinate system workpiece side	4
3.5 Mounting coordinate system	5
3.6 Planes	6
4 Design of the model	6
4.1 General	6
4.2 Necessary properties for the connection interface feature	7
5 Converter, rotationally symmetric	7
5.1 General	7
5.2 Necessary properties	8
5.3 Basic geometry	8
5.4 Connection on workpiece side	10
5.5 Rotational symmetric converter, complete	11
6 Converter, stationary	12
6.1 General	12
6.2 Necessary properties	12
6.3 Basic geometry	13
6.4 Connection on workpiece side	15
6.5 Stationary converter, complete	15
7 Extender	16
7.1 General	16
7.2 Necessary properties	16
7.3 Basic geometry	16
7.4 Connection on workpiece side	17
7.5 Extender, complete	18
8 Reducer, primary design	18
8.1 General	18
8.2 Necessary properties	19
8.3 Basic geometry	19

8.4	Connection on workpiece side	20
8.5	Reducer, primary design, complete	21
9	Reducer, reverse design	21
9.1	General	21
9.2	Necessary properties	22
9.3	Basic geometry	22
9.4	Connection on workpiece side	23
9.5	Reducer, reverse design, complete	23
10	Design of details	24
10.1	Basics for modelling	24
10.2	Contact surfaces, driving features -- Orientation	24
10.3	Chamfers and roundings	24
11	Attributes of surfaces -- Visualization of the model features	25
12	Structure of the design elements (tree of model)	25
13	Data exchange model	26
	Bibliography	27