DIN ISO 16000-41:2024-08 (E)

Indoor air - Part 41: Assessment and classification (ISO 16000-41:2023)

Contents

Page

National foreword 3

National Annex NA (informative) **Bibliography** 6

Foreword 7

Introduction 8

1 Scope 9

2 Normative references 9

3 Terms and definitions 9

4 General 10
4.1 Procedure 10
4.2 Parameters 11

5 Indoor air quality 11

6 Quality classes 11

7 Criteria for the definition of the quality classes 12
7.1 General 12
7.2 Main parameters 12
7.3 Secondary parameters 13

8 Assessment plan 14
8.1 Overview 14
8.2 Documentation and reports 15
8.3 Purpose of measurements 16
8.3.1 Possible reasons 16
8.3.2 Concretisation of assessment 16
8.4 Preliminary survey 16
8.4.1 General 16
8.4.2 Basic investigation 17
8.4.3 Local inspections 17
8.4.4 Conditions for the omission of the measurement of parameters 18
8.5 Investigation plan 18
8.5.1 General 18
8.5.2 Normative specifications 18
8.5.3 Determination of sampling points 19
8.5.4 Utilization of the interior room 19
8.5.5 Seasonal fluctuations and ventilation 19
8.5.6 Complementary outside air measurements 20
8.6 Investigation 20
8.7 Report 20
8.8 Division in quality classes 20

Annex A (informative) **Quality classes for main parameters** 21

Annex B (informative) **Standards for the preliminary survey and the design of investigation plans** 28

Bibliography 31