

# ISO 10497:2010-02 (E)

## Testing of valves - Fire type-testing requirements

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Test conditions .....</b>	<b>2</b>
<b>4.1</b>	<b>Direction and conditions for valves to be tested .....</b>	<b>2</b>
<b>4.2</b>	<b>Pressure relief provision .....</b>	<b>3</b>
<b>5</b>	<b>Fire test method .....</b>	<b>3</b>
<b>5.1</b>	<b>General warning .....</b>	<b>3</b>
<b>5.2</b>	<b>Principle .....</b>	<b>3</b>
<b>5.3</b>	<b>Apparatus .....</b>	<b>3</b>
<b>5.4</b>	<b>Test fluid .....</b>	<b>4</b>
<b>5.5</b>	<b>Test fuel .....</b>	<b>4</b>
<b>5.6</b>	<b>Procedure .....</b>	<b>4</b>
<b>6</b>	<b>Performance .....</b>	<b>10</b>
<b>6.1</b>	<b>General .....</b>	<b>10</b>
<b>6.2</b>	<b>Through-seat leakage during burn period .....</b>	<b>10</b>
<b>6.3</b>	<b>External leakage during burn and cool-down periods .....</b>	<b>10</b>
<b>6.4</b>	<b>Low-pressure test through-seat leakage after cool-down .....</b>	<b>11</b>
<b>6.5</b>	<b>Operability .....</b>	<b>11</b>
<b>6.6</b>	<b>External leakage following operational test .....</b>	<b>11</b>
<b>6.7</b>	<b>Test report .....</b>	<b>12</b>
<b>7</b>	<b>Qualification of other valves by representative size, pressure rating and materials of construction .....</b>	<b>13</b>
<b>7.1</b>	<b>General .....</b>	<b>13</b>
<b>7.2</b>	<b>Materials of construction .....</b>	<b>13</b>
<b>7.3</b>	<b>Qualification of valves by nominal size .....</b>	<b>14</b>
<b>7.4</b>	<b>Qualification of valves by pressure rating .....</b>	<b>14</b>
<b>7.5</b>	<b>Special marking .....</b>	<b>14</b>
Bibliography .....		16