

ISO 4126-6:2003-12 (E)

Safety devices for protection against excessive pressure - Part 6: Application, selection and installation of bursting disc safety devices

Contents		Page
Foreword		v
Introduction		vi
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	Symbols and units	5
5	Application	6
6	Selection	7
6.1	Selection of bursting disc safety devices	7
6.2	Selection of the performance tolerance	8
7	Installation	11
7.1	General	11
7.2	Location of bursting disc safety devices	11
7.3	Installation of bursting disc safety devices	12
Annex A (informative) Information to be supplied by the purchaser		13
A.1	General	13
A.2	Application details	13
A.3	Bursting disc safety device operating details	13
A.4	Installation details	13
A.5	Special details	14
A.6	Language	14
A.7	Replacement bursting discs	14
Annex B (informative) Guidelines for determining the replacement period of a bursting disc		15
B.1	Introduction	15
B.2	Bursting disc safety devices	15
B.3	Replacement period	15
B.4	Methods of determining the replacement period	16
Annex C (informative) Pressure relief system discharge capacity		17
C.1	General	17
C.2	Simplified approach	17
C.3	Comprehensive approach	21
Annex D (informative) Derivation of compressibility factor Z		23
Annex E (informative) Flow testing of bursting disc safety devices		24
E.1	Scope	24

E.2	Test requirements	24
E.3	Method of testing	27
E.4	Test procedure	28
E.5	Determination of flow resistance factor KR	29
E.6	Application of flow resistance factor KR	32
	Bibliography	33