

# ISO 15031-6:2010-08 (E)

## Road vehicles - Communication between vehicle and external equipment for emissions-related diagnostics - Part 6: Diagnostic trouble code definitions

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions, symbols and abbreviated terms .....</b>	<b>2</b>
<b>3.1</b>	<b>Terms and definitions .....</b>	<b>2</b>
<b>3.2</b>	<b>Abbreviated terms .....</b>	<b>2</b>
<b>4</b>	<b>Conventions .....</b>	<b>2</b>
<b>5</b>	<b>Document overview .....</b>	<b>3</b>
<b>6</b>	<b>General specification .....</b>	<b>4</b>
<b>6.1</b>	<b>General code information .....</b>	<b>4</b>
<b>6.2</b>	<b>Sensor location definition .....</b>	<b>4</b>
<b>7</b>	<b>Format structure .....</b>	<b>8</b>
<b>7.1</b>	<b>Description .....</b>	<b>8</b>
<b>7.2</b>	<b>ISO/SAE controlled codes (core DTCs) .....</b>	<b>9</b>
<b>7.3</b>	<b>Manufacturer controlled codes (non-uniform DTCs) .....</b>	<b>9</b>
<b>7.4</b>	<b>Body system groupings -- DTC numbers and descriptions are given in SAE J2012-DA .....</b>	<b>9</b>
<b>7.5</b>	<b>Chassis system groupings -- DTC numbers and descriptions are given in SAE J2012-DA .....</b>	<b>10</b>
<b>7.6</b>	<b>Powertrain system groupings -- DTC numbers and descriptions are given in SAE J2012-DA .....</b>	<b>10</b>
<b>7.7</b>	<b>Generic/Network groupings -- DTC numbers and descriptions are given in SAE J2012-DA .....</b>	<b>10</b>
<b>8</b>	<b>Diagnostic trouble code descriptions .....</b>	<b>11</b>
<b>8.1</b>	<b>Diagnostic trouble code application .....</b>	<b>11</b>
<b>8.2</b>	<b>Powertrain systems .....</b>	<b>11</b>
<b>8.3</b>	<b>Body systems .....</b>	<b>12</b>
<b>8.4</b>	<b>Chassis systems .....</b>	<b>12</b>
<b>8.5</b>	<b>Network and vehicle integration systems .....</b>	<b>12</b>
Bibliography .....		13