

# ISO 12614-8:2014-07 (E)

## Road vehicles - Liquefied natural gas (LNG) fuel system components - Part 8: Excess flow valve

---

<b>Contents</b>		<b>Page</b>
<b>Foreword</b>	.....	<b>iv</b>
<b>1</b>	<b>Scope</b> .....	<b>1</b>
<b>2</b>	<b>Normative references</b> .....	<b>1</b>
<b>3</b>	<b>Terms and definitions</b> .....	<b>1</b>
<b>4</b>	<b>Marking</b> .....	<b>2</b>
<b>5</b>	<b>Construction and assembly</b> .....	<b>2</b>
<b>6</b>	<b>Test</b> .....	<b>3</b>
<b>6.1</b>	<b>Applicability</b> .....	<b>3</b>
<b>6.2</b>	<b>Hydrostatic strength</b> .....	<b>3</b>
<b>6.3</b>	<b>Leakage</b> .....	<b>3</b>
<b>6.4</b>	<b>Excess torque resistance</b> .....	<b>4</b>
<b>6.5</b>	<b>Bending moment</b> .....	<b>4</b>
<b>6.6</b>	<b>Continued operation</b> .....	<b>4</b>
<b>6.7</b>	<b>Operation</b> .....	<b>4</b>
<b>Bibliography</b>	.....	<b>5</b>