

# ISO/TS 16460:2016-09 (E)

## Intelligent transport systems - Communications access for land mobiles (CALM) - Communication protocol messages for global usage

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
1	Scope .....	1
2	Normative references .....	1
3	Terms and definitions .....	1
4	Abbreviated terms .....	2
5	Localized communications messages .....	2
5.1	Purpose .....	2
5.2	Localized message protocol .....	3
5.3	Message formats .....	3
5.4	Networking features .....	4
5.4.1	Subtype values .....	4
5.4.2	Networking feature 0 .....	5
5.4.3	Networking feature 1 .....	5
5.4.4	Networking feature 2 .....	6
5.4.5	N-Extensions .....	7
5.4.6	TPID values .....	7
5.5	Transport features .....	8
5.5.1	Transport feature 0 .....	8
5.5.2	Transport feature 1 .....	9
5.5.3	Transport feature 2 .....	10
5.5.4	T-Extensions .....	11
5.5.5	ITS port numbers .....	11
5.6	Procedures .....	11
6	Service advertisement messages .....	11
6.1	Purpose .....	11
6.2	Unique identifiers .....	12
6.2.1	ITS-AID/PSID .....	12
6.2.2	ITS-PN .....	12
6.3	Service advertisement protocol .....	13
6.4	Service advertisement message .....	13
6.4.1	Messages .....	13
6.4.2	Message structure .....	13
6.4.3	Message header .....	14
6.4.4	Message body .....	16
6.5	Service response message .....	21
6.5.1	Message structure .....	21
6.5.2	Message header .....	22
6.5.3	Message body .....	22
6.6	Count N .....	26
6.7	Procedures .....	26
6.7.1	General .....	26
6.7.2	Privately allocated channels .....	26
6.8	Secured messages .....	27

<b>7</b>	<b>Structure of extension elements .....</b>	<b>28</b>
	<b>Annex A (normative) ASN.1 modules .....</b>	<b>30</b>
	<b>Bibliography .....</b>	<b>43</b>