

# ISO 22241-3:2017-04 (E)

## Diesel engines - NOx reduction agent AUS 32 - Part 3: Handling, transportation, and storage

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>General requirements and recommendations .....</b>	<b>2</b>
<b>4.1</b>	<b>Requirements for use of materials compatible with AUS 32 .....</b>	<b>2</b>
<b>4.1.1</b>	<b>General .....</b>	<b>2</b>
<b>4.1.2</b>	<b>Recommended materials .....</b>	<b>2</b>
<b>4.1.3</b>	<b>Materials not recommended .....</b>	<b>3</b>
<b>4.2</b>	<b>Physical conditions during transportation and storage .....</b>	<b>3</b>
<b>4.2.1</b>	<b>General recommendation .....</b>	<b>3</b>
<b>4.2.2</b>	<b>Shelf life .....</b>	<b>3</b>
<b>4.3</b>	<b>Cleanliness of surfaces in contact with AUS 32 .....</b>	<b>4</b>
<b>4.4</b>	<b>Recommendation on further properties .....</b>	<b>4</b>
<b>5</b>	<b>Quality assurance .....</b>	<b>4</b>
<b>5.1</b>	<b>General .....</b>	<b>4</b>
<b>5.2</b>	<b>Sampling .....</b>	<b>4</b>
<b>5.3</b>	<b>Testing .....</b>	<b>5</b>
<b>5.4</b>	<b>Procedures for product release and handling of non-conforming product .....</b>	<b>5</b>
<b>5.5</b>	<b>Quality monitoring .....</b>	<b>6</b>
<b>5.5.1</b>	<b>General .....</b>	<b>6</b>
<b>5.5.2</b>	<b>Audits .....</b>	<b>6</b>
<b>5.5.3</b>	<b>Documentation .....</b>	<b>6</b>
<b>6</b>	<b>Procedures for handling of containers and equipment .....</b>	<b>7</b>
<b>6.1</b>	<b>General .....</b>	<b>7</b>
<b>6.2</b>	<b>Single use non-bulk containers .....</b>	<b>7</b>
<b>6.3</b>	<b>Dedicated bulk operation .....</b>	<b>7</b>
<b>6.4</b>	<b>Non-dedicated bulk operation .....</b>	<b>8</b>
<b>Bibliography .....</b>		<b>9</b>