DIN EN 16062:2023-10 (E)

Intelligent transport systems - ESafety - eCall high level application requirements (HLAP) using GSM/UMTS circuit switched networks

Contents

Page

European foreword 4

Introduction 5

1 Scope 7

2 Normative references 7

3 Terms and definitions 8

4 Symbols and abbreviations 11

5 Conformance 12

6 General overview of the eCall transaction for Pan European eCall 14

7 Requirements 18
7.1 General requirements 18
7.1.1 General 18
7.1.2 USIM 18
7.1.3 Enabled PSAP 18
7.1.4 IVS configured only for eCall 18
7.1.5 Self-test 19
7.1.6 Standby mode applicable to IVS configured for eCall only 19
7.2 Activation 19
7.2.1 Activation of pan-European eCall 19
7.2.2 Activation of a test eCall 20
7.3 Call set-up 20
7.3.1 General 20
7.3.2 IVS network access device (NAD) already registered on PLMN 20
7.3.3 eCall in progress 20
7.3.4 Network selection and registration 20
7.3.5 Authentication of the subscriber 21
7.3.6 eCall establishment 21
7.3.7 Cell localization (by network) 21
7.3.8 Manual termination of eCall by vehicle occupants before trigger confirmation 22
7.4 MSD transfer 22
7.4.1 General 22
7.4.2 Send initiation signal from IVS eCall modem to PSAP 23
7.4.3 eCall modem synchronization 23
7.4.4 Request MSD by PSAP eCall modem to IVS eCall modem 24
7.4.5 Send MSD from vehicle IVS to PSAP eCall modem 24
7.4.6 Link layer error check 24
7.4.7 Link layer ACK from PSAP eCall modem to IVS eCall modem 24
7.5 Application layer acknowledgement (AL- ACK) 25
7.5.1 Following transmission of the MSD to the eCall PSAP application 25
7.5.2 PSAP acknowledges the MSD 25
7.5.3 No receipt of application layer ACK 25
7.5.4 Form of presentation of the AL-ACK 25
7.6 PSAP request "SEND MSD" 27
7.6.1 General 27

7.6.2 Before call clear-down ... 27
7.6.3 After call clear-down ... 29
7.7 (void) ... 29
7.8 Audio link to vehicle occupants ... 29
7.9 eCall clear-down ... 29
7.10 PSAP call back ... 30
7.11 Rerouting to another PSAP/emergency control centre ... 30
7.12 Handling non equipped situations / error cases ... 31
7.12.1 MSD not transmitted correctly ... 31
7.12.2 Network registration fails ... 31
7.12.3 Call failure before the MSD is sent and acknowledged ... 31
7.12.4 Mobile network not supporting eCall flag or not provided with routing tables ... 31
7.12.5 PSAP modem failure ... 32
7.12.6 PSAP network/ICT failure ... 32
7.12.7 PSAP application failure ... 32
7.12.8 PSAP operator does not respond ... 32
7.12.9 No response if line engaged ... 33
7.12.10 MSD not sent ... 33
7.12.11 MSD not received ... 33
7.12.12 Audio link not established ... 33
7.12.13 Audio link established but subsequently fails ... 34
7.12.14 Re-attempt in case of interrupted call ... 34
7.12.15 Automatic repeat attempts ... 34
7.12.16 IVS NAD does not receive call clear-down ... 34

8 Third party services supported eCall (TPS-eCall) ... 34

9 Defences against attack (Security provisions) ... 35

10 Quality of service requirements ... 35

11 Test and conformance requirements ... 35

12 Marking, labelling and packaging ... 35

13 Declaration of patents and intellectual property ... 35

Annex A (normative) Table of timings ... 36

Annex B (informative) (void) ... 39

Annex C (informative) Test system strategies ... 40

C.1 General ... 40
C.2 Vehicle and PSAP equipment life cycle ... 40
C.3 Laboratory environment ... 41
C.4 OEM or third party test systems ... 41

Bibliography ... 43