

# ISO/TS 12103-3:2023-01 (E)

## Road vehicles - Test contaminants for filter evaluation - Part 3: Soot contaminant

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Symbols and abbreviated terms .....</b>	<b>2</b>
<b>5</b>	<b>Test contaminant .....</b>	<b>3</b>
<b>5.1</b>	<b>Definition .....</b>	<b>3</b>
<b>5.2</b>	<b>Test contaminant designation .....</b>	<b>3</b>
<b>5.3</b>	<b>Generation of soot aerosol .....</b>	<b>3</b>
<b>5.4</b>	<b>Particle size distribution .....</b>	<b>3</b>
<b>5.5</b>	<b>Stability of aerosol concentration and particle size distribution .....</b>	<b>3</b>
<b>5.6</b>	<b>Chemical composition .....</b>	<b>3</b>
<b>6</b>	<b>Analysis equipment and operating procedure .....</b>	<b>4</b>
<b>6.1</b>	<b>General .....</b>	<b>4</b>
<b>6.2</b>	<b>Analysis equipment .....</b>	<b>4</b>
<b>6.3</b>	<b>Particle size analysis procedure .....</b>	<b>4</b>
<b>6.4</b>	<b>Instrument calibration .....</b>	<b>4</b>
	<b>Annex A (normative) Particle size distributions by number .....</b>	<b>5</b>
	<b>Annex B (informative) Handling and use of contaminant .....</b>	<b>8</b>
	<b>Annex C (informative) Concentration .....</b>	<b>9</b>
	<b>Annex D (informative) Flame operation and morphology .....</b>	<b>11</b>
	<b>Annex E (normative) Thermal-optical transmission analysis .....</b>	<b>13</b>
	<b>Annex F (informative) Air-to-fuel ratio .....</b>	<b>15</b>
	<b>Bibliography .....</b>	<b>16</b>