ISO 20176:2006-04 (E)

Road vehicles - H-point machine (HPM II) - Specifications and procedure for H-point determination

Contents

Page

Foreword vi

Introduction vii

1 Scope 1

2 Normative references 1

3 Definitions 2
3.1 H-point 2
3.2 H-point travel path 2
3.3 SgRP (Seating Reference Point), R-point, design H-point 2
3.4 AHP (Accelerator Heel Point) 2
3.5 PRP (Pedal Reference Point) 2
3.6 FRP (Floor Reference Point, rear passenger) 3

4 Measurement procedure for the three-dimensional H-point machine 3
4.1 Summary of installation procedure 3
4.1.1 Measured versus design values 3
4.2 Prepare vehicle and seat 3
4.2.1 Vehicle 3
4.2.2 Seat 4
4.3 Determine the H-point travel path (optional) 4
4.4 Adjust seat to design intent 5
4.4.1 Move seat to design intent position 5
4.4.2 Torso angle and cushion angle 5
4.4.3 Seat in front of test seat 6
4.5 Install HPM cushion and back pan assembly 7
4.5.1 Install the cushion pan 7
4.5.2 Install the back pan 7
4.5.3 Level the HPM 7
4.6 Load the HPM 7
4.6.1 Load the cushion pan 8
4.6.2 Load the back pan 8
4.7 Soak time 8
4.8 Record measurements--digitise HPM points 9
4.8.1 H-point 9
4.8.2 Torso angle and cushion angle 9
4.8.3 Lumbar support prominence 9

5 Optional measurements for driver seat 9
5.1 Leg and shoe installations 9
5.1.1 Mark accelerator pedal centreline 9
5.1.2 Install the shoe fixture 9
5.1.3 Install the shoe tool 9
5.1.4 Install leg segments 10
5.2 Record measurements 10
5.2.1 Pedal Plane Angle 11
5.2.2 Pedal Reference Point 11
5.2.3 Accelerator Heel Point 11
5.2.4 AHP to PRP lateral offset 12

5.2.5 Knee angle and ankle angle 12
5.2.6 Thigh angle and hip angle 12

6 Optional measurements for 2nd or succeeding row passenger seats 12
6.1 Leg and shoe installation 12
6.1.1 Install the shoe tool 12
6.1.2 Install leg segments 13
6.2 Record measurements for rear passengers 15
6.2.1 Floor Reference Point (FRP) 15
6.2.2 Floor Plane Angle 15
6.2.3 Knee clearance and leg room 15

7 Additional optional measurements 15
7.1 Effective head room 15
7.1.1 Install the head room fixture 15
7.1.2 Measure effective head room 16

8 Remove the HPM 16

Annex A (Normative) Description of the Three-Dimensional H-Point Machine (HPM) 17

A.1 Availability 17
A.2 Major components 17
A.2.1 Back pan assembly 17
A.2.2 Cushion pan 17
A.2.3 Lower leg segment 18
A.2.4 Thigh segment 18
A.2.5 Shoe tool and shoe fixture 19
A.2.6 Spring loaded probe 19
A.2.7 Inclinometer (electronic level) 20
A.2.8 Weights 20
A.2.9 Head room fixture 20
A.3 Reference points and angles 20
A.3.1 Pivot locations 20
A.3.2 Support points 20
A.3.3 Divot points 21
A.3.4 Key reference points and lines 22
A.3.5 Posture angles and LSP 23

Annex B (Informative) HPM Specification and Tolerances 25

B.1 Tolerances 25
B.2 Reference posture for specifications 25
B.3 Shoe tool dimensions 26
B.4 Lengths 26
B.5 Widths 26
B.6 Heights 27
B.7 Radii 27
B.8 Weight, HPM only 27
B.9 Support points 28
B.10 Divot point locations 28
B.11 Muslin cloth 29
B.12 Check that HPM is within tolerance specifications 29

Annex C (Informative) HPM Field Checking Procedure 30

C.1 Purpose 30
C.2 Equipment required for checking 30
C.2.1 User provided equipment 30
C.2.2 Checking fixtures 30
C.2.3 Measurement equipment 31
C.3 HPM measurement locations 32

C.4 Summary of measurements and tolerances 33
C.5 Checking procedures 34
C.5.1 Cushion pan 34
C.5.2 LSP scale checks at -15, +25, and 0 36
C.5.3 Back pan 36
C.5.4 Head room probe 38
C.5.5 Thigh segment 39
C.5.6 Leg 39
C.5.7 Data Form 41

D.1.1 File format 42
D.1.2 Datum lines 42

Bibliography 44

Annex D (Informative) H-Point Design (HPD) tool description 42
D.1 H-Point Design tool (HPD) 42