ISO 11486:2006-09 (E)

Motorcycles - Methods for setting running resistance on a chassis dynamometer

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Terms and definitions 1

4 Symbols 2

5 Test motorcycle, chassis dynamometer and instruments 3

6 Required accuracy of measurements 4

7 Road test 4
7.1 Requirement for road 4
7.2 Ambient conditions for the road test 4
7.3 Reference speed 5
7.4 Specified speed 5
7.5 Coastdown starting speed 5
7.6 Coastdown time measurement beginning speed and ending speed 5
7.7 Preparation of test motorcycle 5
7.8 Rider and riding position 6
7.9 Measurement of coastdown time 6

8 Data processing 8
8.1 Calculation of running resistance force 8
8.2 Running resistance curve fitting 8
8.3 Target running resistance force for chassis dynamometer setting 8

9 Chassis dynamometer setting derived from on-road coastdown measurements 8
9.1 Requirements for the equipment 8
9.2 Inertia mass setting 9
9.3 Warming up of chassis dynamometer 9
9.4 Adjustment of tyre pressures 9
9.5 Motorcycle warming up 9
9.6 Procedures for setting chassis dynamometer 9
9.7 Verification of chassis dynamometer 12

10 Chassis dynamometer setting using the running resistance table 12
10.1 Applicability 12
10.2 Requirements for the equipment 12
10.3 Setting the running resistance force on the chassis dynamometer 14
10.4 The specified speed for the chassis dynamometer 14
10.5 Verification of chassis dynamometer 14

Annex A (normative) Motorcycle description 15

Annex B (normative) Chassis dynamometer and instruments description 17

Annex C (informative) Record of coastdown time and chassis dynamometer setting 19

Bibliography 22