ISO 10521-2:2006-10 (E)

Road vehicles - Road load - Part 2: Reproduction on chassis dynamometer

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Terms and definitions 1

4 Required overall measurement accuracy 2

5 Preparation for chassis-dynamometer test 3
5.1 Setting parameter 3
5.2 Laboratory condition 3
5.2.1 Roller 3
5.2.2 Room temperature 3
5.3 Preparation of chassis dynamometer 3
5.3.1 Inertia-mass setting 3
5.3.2 Preconditioning of chassis dynamometer 3
5.4 Vehicle preparation 3
5.4.1 Tyre-pressure adjustment 3
5.4.2 Vehicle setting 4
5.4.3 Vehicle preconditioning 4

6 Load setting on the chassis dynamometer 4
6.1 Chassis-dynamometer setting by coastdown method 4
6.1.1 Load setting of chassis dynamometer 4
6.2 Chassis-dynamometer setting using torquemeter method 5
6.2.1 Load setting of chassis dynamometer 6

Annex A (normative) Calculation of road load for the dynamometer test 8

Annex B (normative) Adjustment of chassis-dynamometer setting load 11