

# ISO 21308-3:2007-02 (E)

## Road vehicles - Product data exchange between chassis and bodywork manufacturers (BEP) - Part 3: General, mass and administrative exchange parameters

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>2</b>
<b>4</b>	<b>Coding system .....</b>	<b>2</b>
4.1	BEP code .....	2
4.2	Type of code .....	2
4.3	Numbering .....	2
4.4	Code assignment and description .....	3
4.5	Priority .....	3
4.6	Loading condition .....	3
4.7	Presented in .....	3
<b>5</b>	<b>BEP code assignment and description .....</b>	<b>4</b>
5.1	General codes .....	4
5.2	Mass codes .....	6
5.3	Administrative codes .....	10
<b>Annex A (informative) Axle configuration designations .....</b>		<b>12</b>
<b>A.1</b>	<b>General information .....</b>	<b>12</b>
<b>A.2</b>	<b>Examples of coding systems used by some chassis manufacturers (CM) .....</b>	<b>12</b>
A.2.1	CM 1 .....	12
A.2.2	CM 2 .....	12
A.2.3	CM 3 .....	12
A.2.4	CM 4 .....	13
A.2.5	CM 5 .....	13
A.3	Examples of designation coding for a specific configuration .....	13
<b>Annex B (informative) Useful tools and related electronic documents .....</b>		<b>14</b>
<b>Bibliography .....</b>		<b>15</b>