

# DIN EN ISO 13789:2008-04 (E)

## Thermal performance of buildings - Transmission and ventilation heat transfer coefficients - Calculation method (ISO 13789:2007)

---

<b>Contents</b>		<b>Page</b>
22	<b>Foreword</b> .....	<b>3</b>
	<b>Introduction</b> .....	<b>4</b>
1	<b>Scope</b> .....	<b>5</b>
2	<b>Normative references</b> .....	<b>5</b>
3	<b>Terms and definitions</b> .....	<b>6</b>
4	<b>Transmission heat transfer coefficient</b> .....	<b>8</b>
5	<b>Ventilation heat transfer coefficient</b> .....	<b>11</b>
6	<b>Transmission heat transfer coefficient through unconditioned spaces</b> .....	<b>11</b>
7	<b>Heat transfer to adjacent buildings</b> .....	<b>12</b>
8	<b>Additional conventions</b> .....	<b>12</b>
9	<b>Report</b> .....	<b>14</b>
	<b>Bibliography</b> .....	<b>22</b>
	<b>Annex B (informative) Information on type of dimensions</b> .....	<b>16</b>
	<b>Annex C (informative) Ventilation airflow rates</b> .....	<b>18</b>
	<b>Annex A (normative) Temperature in an unconditioned space</b> .....	<b>15</b>