

DIN EN ISO 13790:2008-09 (E)

Energy performance of buildings - Calculation of energy use for space heating and cooling (ISO 13790:2008)

Contents	Page
Foreword	4
Introduction	5
1 Scope	8
2 Normative references	9
3 Terms and definitions	10
3.1 Time steps, periods and seasons	10
3.2 Spaces, zones and areas	10
3.3 Temperatures	11
3.4 Energy	12
3.5 Building heat transfer	14
3.6 Building heat gains and recoverable system thermal losses	14
3.7 Building energy balance	15
4 Symbols	15
5 Outline of the calculation procedures	18
5.1 Energy balance of building and systems	18
5.2 Main structure of calculation procedure	19
5.3 Different types of calculation method	22
5.4 Main characteristics of the different methods	22
5.5 Overall energy balances for building and systems	23
6 Definition of boundaries and zones	23
6.1 General	23
6.2 Boundary of the building for the calculation	24
6.3 Thermal zones	24
6.4 Determination of conditioned floor area, Af	27
7 Building energy need for space heating and cooling	28
7.1 Calculation procedure	28
7.2 Energy need for heating and cooling	29
7.3 Multiple steps to integrate or isolate interactions	34
7.4 Length of heating and cooling seasons for operation of season-length-dependent provisions	36
8 Heat transfer by transmission	40
8.1 Calculation procedure	40
8.2 Total heat transfer by transmission per building zone	40
8.3 Transmission heat transfer coefficients	41
8.4 Input data and boundary conditions	44
9 Heat transfer by ventilation	45
9.1 Calculation procedure	45
9.2 Total heat transfer by ventilation per building zone -- Seasonal or monthly method	45
9.3 Ventilation heat transfer coefficients	46
9.4 Input data and boundary conditions	52

10	Internal heat gains	54
10.1	Calculation procedure	54
10.2	Overall internal heat gains	54
10.3	Internal heat gain elements -- All methods	56
10.4	Input data and boundary conditions	56
11	Solar heat gains	60
11.1	Calculation procedure	60
11.2	Overall solar heat gains	61
11.3	Solar heat gain elements	62
11.4	Input data and boundary conditions	64
12	Dynamic parameters	68
12.1	Calculation procedure	68
12.2	Dynamic parameters	69
12.3	Boundary conditions and input data	74
13	Indoor conditions	75
13.1	Different modes	75
13.2	Calculation procedures	76
13.3	Boundary conditions and input data	83
14	Energy use for space heating and cooling	83
14.1	Annual energy needs for heating and cooling, per building zone	83
14.2	Annual energy needs for heating and cooling, per combination of systems	83
14.3	Total system energy use for space heating and cooling and ventilation systems	84
15	Report	88
15.1	General	88
15.2	Input data	88
15.3	Results	89
	Annex A (normative) Parallel routes in normative references	92
	Annex B (normative) Multi-zone calculation with thermal coupling between zones	96
	Annex C (normative) Full set of equations for simple hourly method	100
	Annex D (normative) Alternative formulation for monthly cooling method	105
	Annex E (normative) Heat transfer and solar heat gains of special elements	107
	Annex F (normative) Climate-related data	118
	Annex G (informative) Simplified methods and standard input data	120
	Annex H (informative) Accuracy of the method	134
	Annex I (informative) Explanation and derivation of monthly or seasonal utilization factors	143
	Annex J (informative) Worked example; simple hourly and monthly methods	155
	Annex K (informative) Flow charts of the calculation procedures	161
	Bibliography	168