

# DIN EN 12812:2008-12 (E)

## Falsework - Performance requirements and general design

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
Introduction .....		4
<b>1</b>	<b>Scope .....</b>	<b>5</b>
<b>2</b>	<b>Normative references .....</b>	<b>5</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>6</b>
<b>4</b>	<b>Design classes .....</b>	<b>7</b>
<b>4.1</b>	<b>General .....</b>	<b>7</b>
<b>4.2</b>	<b>Design class A .....</b>	<b>7</b>
<b>4.3</b>	<b>Design class B .....</b>	<b>7</b>
<b>5</b>	<b>Materials .....</b>	<b>8</b>
<b>5.1</b>	<b>General .....</b>	<b>8</b>
<b>5.2</b>	<b>Basic requirements for materials .....</b>	<b>8</b>
<b>5.3</b>	<b>Weldability .....</b>	<b>8</b>
<b>6</b>	<b>Brief .....</b>	<b>8</b>
<b>7</b>	<b>Design requirements .....</b>	<b>8</b>
<b>7.1</b>	<b>General .....</b>	<b>8</b>
<b>7.2</b>	<b>Thickness of material .....</b>	<b>9</b>
<b>7.3</b>	<b>Connections .....</b>	<b>9</b>
<b>7.4</b>	<b>Flexibility of prefabricated support towers .....</b>	<b>9</b>
<b>7.5</b>	<b>Foundation .....</b>	<b>10</b>
<b>7.6</b>	<b>Towers providing support .....</b>	<b>12</b>
<b>8</b>	<b>Actions .....</b>	<b>13</b>
<b>8.1</b>	<b>General .....</b>	<b>13</b>
<b>8.2</b>	<b>Direct actions .....</b>	<b>13</b>
<b>8.3</b>	<b>Indirect actions .....</b>	<b>17</b>
<b>8.4</b>	<b>Other actions "Q9" .....</b>	<b>17</b>
<b>8.5</b>	<b>Load combinations .....</b>	<b>17</b>
<b>9</b>	<b>Structural design for classes B1 and B2 .....</b>	<b>18</b>
<b>9.1</b>	<b>Technical documentation .....</b>	<b>18</b>
<b>9.2</b>	<b>Structural design .....</b>	<b>20</b>
<b>9.3</b>	<b>Imperfections and boundary conditions .....</b>	<b>23</b>
<b>9.4</b>	<b>Calculation of internal forces .....</b>	<b>30</b>
<b>9.5</b>	<b>Characteristic values of resistance and friction values .....</b>	<b>37</b>
<b>Annex A (informative) Relation with site activities .....</b>		<b>40</b>
<b>Annex B (informative) .....</b>		<b>41</b>
<b>Bibliography .....</b>		<b>42</b>