DIN EN 1995-1-2: 2010-12(E)

Eurocode_5: Design of timber structures_- Part_1-2: General_- Structural fire design (includes Corrigendum AC:2009)

Contents

Foreword to EN 1995-1-2:2004 + AC:2009 4
Background of the Eurocode programme 4
Status and field of application of Eurocodes 5
National Standards implementing Eurocodes 5
Links between Eurocodes and harmonised technical specifications (ENs and ETAs) for products 6
Additional information specific to EN 1995-1-2 6
National annex for EN 1995-1-2 7
Section 1 General 9
1.1 Scope 9
1.1.1 Scope of Eurocode 5 9
1.1.2 Scope of EN 1995-1-2 9
1.2 Normative references 10
1.3 Assumptions 10
1.4 Distinction between principles and application rules 10
1.5 Terms and definitions 11
1.6 Symbols 11
Section 2 Basis of design 14
2.1 Requirements 14
2.1.1 Basic requirements 14
2.1.2 Nominal fire exposure 14
2.1.3 Parametric fire exposure 14
2.2 Actions 15
2.3 Design values of material properties and resistances 15
2.4 Verification methods 16
2.4.1 General 16
2.4.2 Member analysis 17
2.4.3 Analysis of parts of the structure 18
2.4.4 Global structural analysis 19
Section 3 Material properties 20
3.1 General 20
3.2 Mechanical properties 20
3.3 Thermal properties 20
3.4 Charring depth 20
3.4.1 General 20
3.4.2 Surfaces unprotected throughout the time of fire exposure 21
3.4.3 Surfaces of beams and columns initially protected from fire exposure 23
3.4.3.1 General 23
3.4.3.2 Charring rates 26
3.4.3.3 Start of charring 27
3.4.3.4 Failure times of fire protective claddings 28
3.5 Adhesives 29
Section 4 Design procedures for mechanical resistance 30
4.1 General 30
4.2 Simplified rules for determining cross-sectional properties 30
4.2.1 General 30
4.2.2 Reduced cross-section method 30
4.2.3 Reduced properties method 31
4.3 Simplified rules for analysis of structural members and components 32
4.3.1 General 32
4.3.2 Beams 32
4.3.3 Columns 33
4.3.4 Mechanically jointed members 33
4.3.5 Bracings 34
4.4 Advanced calculation methods 34
Section 5 Design procedures for wall and floor assemblies 35

5.1 General 35
5.2 Analysis of load-bearing function 35
5.3 Analysis of separating function 35
Section 6 Connections 36
6.1 General 36
6.2 Connections with side members of wood 36
6.2.1 Simplified rules 36
6.2.1.1 Unprotected connections 36
6.2.1.2 Protected connections 37
6.2.1.3 Additional rules for connections with internal steel plates 38
6.2.2 Reduced load method 39
6.2.2.1 Unprotected connections 39
6.2.2.2 Protected connections 41
6.3 Connections with external steel plates 41
6.3.1 Unprotected connections 41
6.3.2 Protected connections 41
6.4 Simplified rules for axially loaded screws 41
Section 7 Detailing 43
7.1 Walls and floors 43
7.1.1 Dimensions and spacings 43
7.1.2 Detailing of panel connections 43
7.1.3 Insulation 43
7.2 Other elements 43
Annex A (informative) Parametric fire exposure 45
A1 General 45
A2 Charring rates and charring depths 45
A3 Mechanical resistance of members in edgewise bending 47
Annex B (informative) Advanced calculation methods 48
B1 General 48
B2 Thermal properties 48
B3 Mechanical properties 50
Annex C (informative) Load-bearing floor joists and wall studs in assemblies whose cavities are completely filled with insulation 52
C1 General 52
C2 Residual cross-section 52
C2.1 Charring rates 52
C2.2 Start of charring 54
C2.3 Failure times of panels 54
C3 Reduction of strength and stiffness parameters 56
Annex D (informative) Charring of members in wall and floor assemblies with void cavities 58
D1 General 58
D2 Charring rates 58
D3 Start of charring 58
D4 Failure times of panels 58
Annex E (informative) Analysis of the separating function of wall and floor assemblies 60
E1 General 60
E2 Simplified method for the analysis of insulation 60
E2.1 General 60
E2.2 Basic insulation values 61
E2.3 Position coefficients 62
E2.4 Effect of joints 62
Annex F (informative) Guidance for users of this Eurocode Part 68