ISO 22476-6:2018 (E)

Geotechnical investigation and testing — Field testing — Part 6: Self-boring pressuremeter test

Contents

Foreword

1 Scope

2 Normative references

3 Terms and definitions

4 Symbols

5 Equipment

- 5.1 General
- 5.2 Self-boring pressuremeter probe
- 5.3 Self-boring head
- 5.4 Pressure and displacement CU
- 5.5 The connecting lines
- 5.6 The injected fluid
- 5.7 Means of measurement and control
- 5.7.1 Data acquisition
- 5.7.2 Display of readings

6 Test procedure

- 6.1 Selection of equipment and procedures
- 6.2 Calibration of the testing device and corrections of readings
- 6.3 Probe placing
- 6.4 Relaxation
- 6.5 Loading program
- 6.5.1 General
- 6.5.2 End of test
- 6.6 Backfilling of the borehole

7 Test results — Interpretation of tests

8 Self-boring pressuremeter test report

Annex A (normative) Calibration and corrections

- A.1 Measuring devices
- A.2 Stiffness of cell membranes
- A.2.1 Preparation of the self-boring pressuremeter for a membrane pressure loss test
- A.2.2 Membrane stiffness correction test
- A.3 Membrane compression
- A.3.1 The calibration cylinder
- A.3.2 Membrane compression test
- A.4 Estimate of readings corrections

Annex B (informative) Placing the pressuremeter probe in the ground

- B.1 General
- B.2 Selecting self-boring tool

Annex C (normative) Accuracy

- C.1 Accuracy of the measuring devices

Annex D (informative) Strain conversions

Page count: 21