

# ISO 10563:2023-06 (E)

## Building and civil engineering sealants - Determination of change in mass and volume

---

<b>Contents</b>		<b>Page</b>
Foreword.....		iv
<b>1</b>	<b>Scope</b> .....	<b>1</b>
<b>2</b>	<b>Normative references</b> .....	<b>1</b>
<b>3</b>	<b>Terms and definitions</b> .....	<b>1</b>
<b>4</b>	<b>Principle</b> .....	<b>1</b>
<b>5</b>	<b>Apparatus and materials</b> .....	<b>1</b>
<b>6</b>	<b>Preparation of test specimens</b> .....	<b>2</b>
6.1	For non-sagging sealant.....	2
6.2	For self-levelling sealant.....	2
<b>7</b>	<b>Test procedure</b> .....	<b>3</b>
7.1	General.....	3
7.2	Preconditioning.....	3
7.3	Specific conditioning.....	3
<b>8</b>	<b>Calculation and expression of results</b> .....	<b>3</b>
8.1	Change in mass.....	3
8.2	Change in volume.....	4
<b>9</b>	<b>Test report</b> .....	<b>4</b>