

# DIN EN ISO 19116:2025-08 (E)

## Geographic information - Positioning services (ISO 19116:2025); English version EN ISO 19116:2025

---

<b>Contents</b>		<b>Page</b>
Foreword		v
Introduction		vi
<b>1</b>	<b>Scope</b>	<b>1</b>
<b>2</b>	<b>Normative references</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions</b>	<b>1</b>
<b>4</b>	<b>Symbols, abbreviated terms, backwards compatibility, UML notation, and packages</b>	<b>6</b>
4.1	Symbols and abbreviated terms	6
4.2	Backwards compatibility	7
4.3	UML notation	7
4.4	Package abbreviations	7
<b>5</b>	<b>Conformance</b>	<b>7</b>
5.1	Overview	7
5.2	Conformance requirements	8
5.3	Structure of requirements clauses	8
<b>6</b>	<b>Positioning services model</b>	<b>8</b>
6.1	Overview	8
6.2	Static data structures of a positioning service	9
6.3	Basic and extended information from a positioning service	10
<b>7</b>	<b>Basic information: definition and description</b>	<b>11</b>
7.1	Overview	11
7.2	System information	12
7.2.1	Overview	12
7.2.2	PS_System	13
7.2.3	System capability	14
7.2.4	Positioning technology	14
7.2.5	Referencing method	15
7.2.6	Instrument identification	15
7.3	Session information	16
7.3.1	Overview	16
7.3.2	PS_Session	16
7.4	Observation information	17
7.4.1	Overview	17
7.4.2	PS_ObservationMode	18
7.4.3	PS_LinkToReferenceSystem	21
7.4.4	PS_MeasurementType	21
7.4.5	Observation	21
7.4.6	Coordinate transfer (offset) values	23
7.4.7	Offset vector	25
7.4.8	PS_OffsetSourceType	25
7.5	Quality information	25
7.5.1	Overview	25
7.5.2	PS_QualityMode	27
7.6	Positioning services operations	28
7.6.1	Definition of positioning services operations	28
7.6.2	Requirements for positioning service operations	29
7.6.3	Applying the positioning services operations	31

<b>8</b>	<b>Reliability of positioning results</b> .....	<b>31</b>
8.1	Overview .....	31
8.2	Reliability model .....	32
<b>9</b>	<b>Technology-specific information</b> .....	<b>34</b>
9.1	Overview .....	34
9.2	Operating conditions .....	34
9.2.1	PS_OperatingConditions .....	34
9.2.2	PS_ComputationalConditions .....	35
9.2.3	PS_PositionFixMode .....	35
9.2.4	PS_PositioningMode .....	35
9.2.5	PS_ProcessingMode .....	36
9.2.6	Performance indicators .....	36
9.2.7	Measurement conditions .....	36
9.3	Raw measurement data .....	37
<b>Annex A (normative)</b>	<b>Conformance</b> .....	<b>38</b>
<b>Annex B (informative)</b>	<b>Implementing accuracy reports for positioning services</b> .....	<b>40</b>
<b>Annex C (informative)</b>	<b>Overview of positioning services</b> .....	<b>44</b>
<b>Annex D (informative)</b>	<b>GNSS operating conditions</b> .....	<b>46</b>
<b>Annex E (informative)</b>	<b>Reliability evaluation methods</b> .....	<b>51</b>
<b>Annex F (informative)</b>	<b>Examples for extending positioning service results</b> .....	<b>57</b>
<b>Annex G (informative)</b>	<b>Use case examples</b> .....	<b>59</b>
<b>Bibliography</b>	.....	<b>62</b>