

# ISO 13694:2000-04 (E)

## Optics and optical instruments - Lasers and laser-related equipment - Test methods for laser beam power [energy] density distribution

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
3.1	Measured quantities .....	1
3.2	Characterizing parameters .....	3
3.3	Distribution fitting .....	6
<b>4</b>	<b>Coordinate system .....</b>	<b>7</b>
<b>5</b>	<b>Characterizing parameters derived from the measured spatial distribution .....</b>	<b>7</b>
<b>6</b>	<b>Distribution fitting .....</b>	<b>7</b>
6.1	General .....	7
6.2	Fitting procedures .....	8
<b>7</b>	<b>Test principle .....</b>	<b>9</b>
<b>8</b>	<b>Measurement arrangement and test equipment .....</b>	<b>9</b>
8.1	General .....	9
8.2	Preparation .....	9
8.3	Control of environment .....	10
8.4	Detector system .....	10
8.5	Beam-forming optics, optical attenuators and beam splitters .....	10
<b>9</b>	<b>Test procedures .....</b>	<b>11</b>
9.1	Equipment preparation .....	11
9.2	Detector calibration procedure .....	11
9.3	Data recording and noise correction .....	12
<b>10</b>	<b>Evaluation .....</b>	<b>13</b>
10.1	Choice and optimization of integration limits .....	13
10.2	Control and optimization of background corrections .....	13
<b>11</b>	<b>Test report .....</b>	<b>14</b>