

# DIN EN 16905-2:2020-03 (E)

## Gas-fired endothermic engine driven heat pumps - Part 2: Safety

---

### Contents

Page

European foreword.....	4
1 Scope.....	5
1.1 Scope of EN 16905.....	5
1.2 Scope of EN 16905-2.....	5
2 Normative references.....	6
3 Terms and definitions .....	7
4 Classification.....	8
4.1 General.....	8
4.2 Classification of GEHP appliances .....	8
4.3 GEHP appliance classification according to the maximum water side operating pressure (PMS): .....	8
5 Design requirements .....	9
5.1 Structure.....	9
5.2 Material.....	12
5.3 EMC / electrical requirements .....	19
6 Operational requirements.....	20
6.1 General requirements .....	20
6.2 Soundness .....	20
6.3 Heat input at standard rating conditions .....	21
6.4 Limit temperatures .....	21
6.5 Limit operating conditions .....	22
6.6 Insulation resistance .....	22
6.7 Transient overvoltage .....	22
6.8 Withstand voltage .....	23
6.9 Waterproof performance .....	23
6.10 Sound power level.....	23
6.11 Engine perform .....	23
6.12 Power failure .....	25
6.13 Abnormalities.....	25
6.14 Starting current .....	25
7 Test methods .....	25
7.1 General test conditions .....	25
7.2 Soundness .....	27
7.3 Heat input at standard rating conditions .....	29
7.4 Limit temperatures .....	29
7.5 Limit operating conditions .....	30
7.6 Insulation resistance test.....	31
7.7 Transient overvoltage test.....	31
7.8 Withstand voltage test.....	31
7.9 Waterproof performance test.....	31
7.10 Sound power level test.....	32
7.11 Engine performance.....	32
7.12 Power failure test.....	33
7.13 Abnormalities test .....	33

<b>7.14</b>	<b>Starting current test .....</b>	<b>33</b>
<b>8</b>	<b>Risk assessment .....</b>	<b>33</b>
<b>9</b>	<b>Marking and instructions .....</b>	<b>34</b>
<b>9.1</b>	<b>GEHP appliance marking .....</b>	<b>34</b>
<b>9.2</b>	<b>Installation instructions.....</b>	<b>36</b>
<b>9.3</b>	<b>User's instructions.....</b>	<b>38</b>
<b>9.4</b>	<b>Gas conversion instructions.....</b>	<b>38</b>
<b>9.5</b>	<b>Presentation .....</b>	<b>39</b>
<b>Annex A (informative) Calculation of conversion of NO<sub>X</sub>.....</b>		<b>40</b>
<b>Annex B (normative) Engine startup test method .....</b>		<b>41</b>
<b>B.1</b>	<b>General .....</b>	<b>41</b>
<b>B.2</b>	<b>Test condition .....</b>	<b>41</b>
<b>B.3</b>	<b>Test method.....</b>	<b>41</b>
<b>Annex C (normative) CO concentration test method .....</b>		<b>42</b>
<b>C.1</b>	<b>General .....</b>	<b>42</b>
<b>C.2</b>	<b>Test condition .....</b>	<b>42</b>
<b>Annex D (normative) NO<sub>X</sub> concentration test method.....</b>		<b>45</b>
<b>D.1</b>	<b>Definitions.....</b>	<b>45</b>
<b>D.2</b>	<b>General .....</b>	<b>45</b>
<b>Annex E (normative) Power failure test method.....</b>		<b>48</b>
<b>E.1</b>	<b>General .....</b>	<b>48</b>
<b>E.2</b>	<b>Test method.....</b>	<b>48</b>
<b>Annex F (informative) Examples for marking.....</b>		<b>49</b>
<b>F.1</b>	<b>Data-plate (see 9.1.1) .....</b>	<b>49</b>
<b>F.2</b>	<b>Additional data-plate (see 9.1.2).....</b>	<b>49</b>
<b>Annex G (informative) Examples for NO<sub>X</sub> calculation .....</b>		<b>50</b>
<b>G.1</b>	<b>E<sub>rpm</sub> equivalent calculation .....</b>	<b>50</b>
<b>G.2</b>	<b>NO<sub>X</sub> ppm to mg/kWh conversation.....</b>	<b>50</b>
<b>G.3</b>	<b>Temperature and humidity correction formula calculation .....</b>	<b>50</b>
<b>Bibliography .....</b>		<b>51</b>