

# DIN EN 17922:2024-08 (E)

## Natural gas fuelling stations - LNG unloading stop system

---

<b>Contents</b>		<b>Page</b>
European foreword .....		3
Introduction .....		4
1	Scope .....	5
2	Normative references .....	5
3	Terms and definitions .....	5
4	Functional requirements .....	6
4.1	General requirement .....	6
4.2	Functional description of the unloading stop system .....	7
4.3	Alarms and actions for unloading stop system .....	8
4.3.1	Manual triggers for unloading stop .....	8
4.3.2	Automatic triggers for unloading stop .....	8
5	Design of the unloading stop system .....	10
5.1	General .....	10
5.2	Activation time .....	10
5.3	Air pressure alarm .....	10
6	Technical description of unloading stop system .....	10
6.1	Pneumatic system .....	10
6.1.1	General .....	10
6.1.2	Pressure rating .....	10
6.2	Pneumatic system connector .....	10
6.2.1	Technical drawing .....	10
6.2.2	Profile of the pneumatic connector .....	10
7	Operation of unloading stop system .....	11
7.1	Testing of the pneumatic link .....	11
7.2	Resume operation after ESD action .....	11
Bibliography .....		12