

ISO 5124:2024-10 (E)

Loading and unloading of liquefied natural gas (LNG) tank wagons and containers

Contents		Page
Foreword		iv
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	Equipment design	3
4.1	LNG tank wagon	3
4.2	LNG tank container	3
4.3	Tanks for LNG tank wagons and tank containers	3
4.4	Loading or unloading bay configuration	6
4.5	Connection couplings	8
4.5.1	Type and size of connections	8
4.5.2	Quick connect disconnect coupler (QDC)	8
4.5.3	Emergency release coupling (ERC)	8
4.6	LNG transfer hoses or arms	8
4.7	General process design requirements	9
4.7.1	General	9
4.7.2	Overfill detection and overpressurization	9
4.7.3	Loading and unloading process	10
4.7.4	Quantity and quality measurement	10
4.7.5	Sampling	11
4.7.6	Predicting LNG quality change due to ageing	11
5	Leak and fire management	11
5.1	Leak avoidance, detection and management	11
5.1.1	General	11
5.1.2	Avoidance	11
5.1.3	Gas detection	12
5.1.4	Management	12
5.2	Fire avoidance, detection and management strategies	13
5.2.1	Fire avoidance	13
5.2.2	Fire detection	13
5.2.3	Fire management	13
6	Layout considerations	13
6.1	Safety separation distances	13
6.2	Typical equipment layout	13
6.3	Buildings	13
7	Commissioning and start-up	14
8	Operations	15
8.1	Initial checks	15
8.2	Weighing before loading or unloading operation	15
8.3	Loading terminal	16
9	Stakeholder analysis	16
Bibliography		18