

# DIN ISO 20816-8:2018-12 (E)

## Mechanical vibration - Measurement and evaluation of machine vibration - Part 8: Reciprocating compressor systems (ISO 20816-8:2018)

---

<b>Contents</b>	<b>Page</b>
<b>National foreword</b> .....	<b>3</b>
<b>National Annex NA (informative) Bibliography</b> .....	<b>5</b>
<b>Foreword</b> .....	<b>6</b>
<b>Introduction</b> .....	<b>7</b>
<b>1 Scope</b> .....	<b>8</b>
<b>2 Normative references</b> .....	<b>8</b>
<b>3 Terms and definitions</b> .....	<b>9</b>
<b>4 Measurements</b> .....	<b>10</b>
4.1 Measurement procedure .....	10
4.2 Measuring instrumentation and measured quantities .....	10
4.3 Locations and direction of measurements .....	11
4.3.1 Locations .....	11
4.3.2 Direction of measurements .....	16
4.4 Operating conditions .....	17
4.5 Record of measured results .....	17
<b>5 Vibration criteria</b> .....	<b>17</b>
5.1 Measuring quantities .....	17
5.2 Evaluation zones .....	17
5.2.1 General .....	17
5.2.2 Acceptance criteria .....	18
5.3 Guidance values for acceptable overall vibration values (2 Hz to 1 000 Hz) .....	19
5.3.1 Guidance value tables for displacement, velocity and acceleration .....	19
5.3.2 Vibration values and the effect of mountings and foundations .....	20
5.3.3 Vibration values for horizontal compressors .....	20
5.3.4 Vibration values for vertical compressors .....	20
<b>Annex A (normative) Measurement information requirements</b> .....	<b>21</b>
<b>Annex B (informative) Curves with overall limits of vibration velocity values</b> .....	<b>24</b>
<b>Annex C (informative) Measurement of vibration values on the crosshead guide</b> .....	<b>30</b>
<b>Annex D (informative) Root-mean-square value, peak value and crest factor</b> .....	<b>33</b>
<b>Annex E (normative) Small bore connections (SBC)</b> .....	<b>35</b>
<b>Bibliography</b> .....	<b>41</b>