







DIN EN 13015 :2008-12 (E)

Maintenance for lifts and escalators_ - Rules for maintenance instructions (includes Amendment A1:2008)

Contents	Page
Foreword.....	3
0 Introduction	3
1 Scope	3
2 Normative references	3
3 Definitions	4
4 Elaboration of maintenance instructions	5
4.1 General.....	5
4.2 Elements to be taken into account for the maintenance instructions	6
4.3 Information to be included in the maintenance instructions	6
4.3.1 General	6
4.3.2 Information to the owner of the installation.....	6
4.3.3 Information for the maintenance organisation	9
5 Risk assessment.....	10
5.1 General.....	10
5.2 Information for the maintenance organisation	11
6 Information to the owner for lift rescue operations	11
7 Markings, signs, pictograms and written warnings	12
8 Format of the maintenance instruction handbook.....	12
Annex A (informative) Typical examples of checks to be taken into account in maintenance instructions	13
Annex B (informative) Examples of elements to be taken into account in risk assessment for maintenance operations	17
Annex ZA (informative)  Relationship between this European Standard and the Essential Requirements of EC Directive 98/37/EC 	19
Annex ZB (informative)  Relationship between this European Standard and the Essential Requirements of EC Directive 2006/42/EC 	20
Annex ZC (informative)  Relationship between this European Standard and the Essential Requirements of EC Directive 95/16/EC 	21