

ISO 6016:2008-12 (E)

Earth-moving machinery - Methods of measuring the masses of whole machines, their equipment and components

| Contents | | Page |
|-----------------------|---|-------------|
| Foreword | | iv |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms and definitions | 1 |
| 3.1 | General definitions | 1 |
| 3.2 | Masses | 3 |
| 3.3 | Measurements | 4 |
| 3.4 | Apparatus | 4 |
| 4 | Preparation for testing | 4 |
| 5 | Methods for measuring mass | 5 |
| 5.1 | General | 5 |
| 5.2 | Precision of measurement apparatus | 5 |
| 5.3 | Single measurement method | 5 |
| 5.4 | Cumulative measurement method | 7 |
| 5.5 | Measurement of axle load | 8 |
| 5.6 | Determination of mass of equipment, attachment or components | 8 |
| 6 | Reporting measurement results | 8 |