

DIN EN 14017:2009-12 (E)

Agricultural and forestry machinery - Solid fertilizer distributors - Safety (includes Amendment A2:2009)

Contents

	Page
Foreword.....	3
Introduction	4
1 Scope	5
2 Normative references	6
3 Terms and definitions	6
4 List of significant hazards	7
5 Safety requirements and/or protective measures	8
5.1 General.....	8
5.2 Stability when parked and for manual handling.....	8
5.2.1 General.....	8
5.2.2 Mounted machines fitted with rollers for manual handling when dismantled.....	9
5.2.3 Machines with adjustable supporting devices	9
5.3 Distributing components	9
5.3.1 Swivelling and movable components.....	9
5.3.2 Spreading plates and oscillating tubes.....	9
5.4 Feeding components guarding	13
5.5 Loading	13
5.5.1 Safe access for loading.....	13
5.5.2 Boarding means to loading location.....	14
5.6 Checking of the hopper contents.....	15
5.7 Protection against ejection of fertilizer	16
5.8 Removal of the spreading device.....	16
5.9 Flow rate calibration system	16
5.10 Hitching and clearance zone	16
5.11 Noise	18
5.11.1 Noise reduction as a safety requirement	18
5.11.2 Verification of requirements on noise based on noise emission values.....	18
6 Verification of the safety requirements and/or protective measures.....	18
6.1 Stability when parked and for manual handling.....	18
6.1.1 General.....	18
6.1.2 Mounted machines fitted with rollers for manual handling when dismantled.....	18
6.2 Swivelling and movable components.....	18
7 Information for use	19
7.1 Instruction handbook.....	19
7.2 Marking	20
Annex A (informative) Stability of the tractor distributor combination	21
Annex B (informative) Examples of pictograms.....	22
Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 98/37/EC	24
Annex ZB (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC	25
Bibliography	26