

ISO/TS 17165-2:2013-04 (E)

Hydraulic fluid power - Hose assemblies - Part 2: Practices for hydraulic hose assemblies

| Contents | | Page |
|--------------------|--|-------------|
| Foreword | | v |
| Introduction | | vi |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms and definitions | 2 |
| 4 | Safety considerations | 2 |
| 4.1 | General | 2 |
| 4.2 | Fluid injections | 2 |
| 4.3 | Whipping hoses | 2 |
| 4.4 | Burns from conveyed fluids | 3 |
| 4.5 | Fire and explosions from conveyed fluids | 3 |
| 4.6 | Fire and explosions from static-electric discharge | 3 |
| 4.7 | Electrical shock | 3 |
| 4.8 | Mechanisms controlled by fluid power | 3 |
| 5 | Hose selection and routing | 3 |
| 5.1 | General | 3 |
| 5.2 | System pressures | 3 |
| 5.3 | Suction | 4 |
| 5.4 | External pressure | 4 |
| 5.5 | Temperature | 4 |
| 5.6 | Permeation | 4 |
| 5.7 | Compatibility between hose materials and system fluids | 4 |
| 5.8 | Environment | 4 |
| 5.9 | Static-electric discharge | 5 |
| 5.10 | Sizing | 5 |
| 5.11 | Unintended uses | 5 |
| 5.12 | Specifications and standards | 5 |
| 5.13 | Unusual applications | 5 |
| 5.14 | Hose assembly cleanliness | 5 |
| 5.15 | Hose fittings | 5 |
| 5.16 | Vibration | 6 |
| 5.17 | Hose cover protection | 6 |
| 5.18 | External physical abuse | 6 |
| 5.19 | Swivel hose fittings and connectors | 7 |
| 5.20 | Rotary connectors | 7 |
| 5.21 | Slings and clamps | 7 |
| 5.22 | Minimum bend radius | 7 |
| 5.23 | Elbows and connectors | 8 |
| 5.24 | Lengths | 8 |
| 5.25 | Hose movement and bending | 9 |
| 6 | Hose assembly fabrication | 11 |
| 6.1 | General | 11 |
| 6.2 | Component inspection | 11 |
| 6.3 | Hose fitting parts | 11 |

| | | |
|--|--|----|
| 6.4 | Compatibility between hose and hose fittings | 11 |
| 6.5 | Hose assembly equipment | 11 |
| 6.6 | Safety equipment | 12 |
| 6.7 | Condition of hose assembly parts | 12 |
| 6.8 | Cleanliness of hoses and hose assemblies | 12 |
| 6.9 | Temperature | 12 |
| 6.10 | Assembly inspection | 12 |
| 6.11 | Marking | 12 |
| 7 | Hose installation and replacement | 12 |
| 7.1 | General | 12 |
| 7.2 | Pre-installation inspection | 12 |
| 7.3 | Handling during installation | 13 |
| 7.4 | Twist angle and orientation | 13 |
| 7.5 | Securing and protection | 13 |
| 7.6 | Routing | 13 |
| 7.7 | Assembly torque | 13 |
| 7.8 | System checkouts | 14 |
| 8 | Maintenance inspection | 14 |
| 8.1 | General | 14 |
| 8.2 | Inspection frequency | 14 |
| 8.3 | Visual inspection (hose and hose fittings) | 14 |
| 8.4 | Visual inspection (all other components in the system) | 15 |
| 8.5 | Functional tests | 15 |
| 9 | Storage | 15 |
| 9.1 | General | 15 |
| 9.2 | Age control | 15 |
| 9.3 | Storage conditions | 16 |
| 10 | Identification statement (reference to this part of ISO 17165) | 16 |
| Annex A (informative) Examples of actual failure resulting from improper use | | 17 |