

ISO 12140:2013-07 (E)

Agricultural machinery - Agricultural trailers and trailed equipment - Drawbar jacks

Contents		Page
Foreword		iv
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	Requirements	4
4.1	Crank effort	4
4.2	Overtravel	4
4.3	Ground pressure	4
4.4	Corrosion protection	4
4.5	Service life	4
4.6	Rated static compressive load capacity	4
4.7	Rated dynamic compressive load capacity	4
4.8	Rated static tensile load capacity	4
4.9	Rated dynamic tensile load capacity	5
4.10	Rated static side load capacity	5
4.11	Rated static side torque class	5
4.12	Crank assembly	5
4.13	Prevention of ground contact when not in use	5
4.14	Security in operating position	6
4.15	Hydraulic components and fittings	6
4.16	Application performance	6
5	Marking	7
6	Acceptance tests -- Installation and procedures	8
6.1	General procedures and installation of jack	8
6.2	Jack stand system design verification tests	8
6.3	Jack stand system application tests	9
7	Information for use	10
Bibliography		11