

# ISO 10300-2:2014-04 (E)

## Calculation of load capacity of bevel gears - Part 2: Calculation of surface durability (pitting)

---

Contents	Page
<b>Foreword .....</b>	<b>iv</b>
<b>Introduction .....</b>	<b>v</b>
<b>1 Scope .....</b>	<b>1</b>
<b>2 Normative references .....</b>	<b>1</b>
<b>3 Terms and definitions .....</b>	<b>1</b>
<b>4 Symbols, units and abbreviated terms .....</b>	<b>2</b>
<b>5 Pitting damage -- General aspects .....</b>	<b>3</b>
<b>5.1 Acceptable versus unacceptable pitting .....</b>	<b>3</b>
<b>5.2 Assessment requirements .....</b>	<b>3</b>
<b>5.3 General rating procedure .....</b>	<b>4</b>
<b>6 Gearflank rating formulae--MethodB1 .....</b>	<b>4</b>
<b>6.1 Contact stress formula .....</b>	<b>4</b>
<b>6.2 Permissible contact stress .....</b>	<b>6</b>
<b>6.3 Calculated safety factor for contact stress .....</b>	<b>6</b>
<b>6.4 Contact stress factors .....</b>	<b>6</b>
<b>6.5 Permissible contact stress factors .....</b>	<b>10</b>
<b>7 Gearflank rating formulae--MethodB2 .....</b>	<b>13</b>
<b>7.1 Contact stress formula .....</b>	<b>13</b>
<b>7.2 Permissible contact stress .....</b>	<b>14</b>
<b>7.3 Calculated safety factor for contact stress .....</b>	<b>14</b>
<b>7.4 Contact stress factors .....</b>	<b>15</b>
<b>8 Factors for contact stress and permissible contact stress common for methodB1 and methodB2 .....</b>	<b>20</b>
<b>8.1 Elasticity factor, ZE .....</b>	<b>20</b>
<b>8.2 Lubricant film influence factors, ZL, Zv, ZR .....</b>	<b>20</b>
<b>8.3 Work hardening factor, ZW .....</b>	<b>24</b>
<b>8.4 Life factor, ZNT .....</b>	<b>25</b>
<b>Annex A (informative) Bevel slip factor ZS--MethodB1 .....</b>	<b>28</b>
<b>Bibliography .....</b>	<b>30</b>