

# ISO 18893:2014-04 (E)

## Mobile elevating work platforms - Safety principles, inspection, maintenance and operation

---

Contents	Page
<b>Foreword .....</b>	<b>iv</b>
<b>Introduction .....</b>	<b>v</b>
<b>1 Scope .....</b>	<b>1</b>
<b>2 Normative references .....</b>	<b>1</b>
<b>3 Terms and definitions .....</b>	<b>1</b>
<b>4 General requirements .....</b>	<b>2</b>
<b>4.1 Basic principles .....</b>	<b>2</b>
<b>4.2 System of work .....</b>	<b>3</b>
<b>4.3 Manuals (handbooks) .....</b>	<b>3</b>
<b>4.4 Record retention .....</b>	<b>4</b>
<b>4.5 Modifications .....</b>	<b>4</b>
<b>5 Maintenance .....</b>	<b>4</b>
<b>5.1 Preventive maintenance .....</b>	<b>4</b>
<b>5.2 Maintenance inspections .....</b>	<b>4</b>
<b>5.3 Maintenance personnel training .....</b>	<b>6</b>
<b>5.4 Maintenance and repair safety precautions .....</b>	<b>6</b>
<b>5.5 Replacement parts .....</b>	<b>7</b>
<b>5.6 Manufacturer's safety bulletins .....</b>	<b>7</b>
<b>6 Operation .....</b>	<b>7</b>
<b>6.1 Planning .....</b>	<b>7</b>
<b>6.2 Operator training .....</b>	<b>9</b>
<b>6.3 Familiarization .....</b>	<b>9</b>
<b>6.4 Assistance to operators .....</b>	<b>9</b>
<b>6.5 Before operation .....</b>	<b>9</b>
<b>6.6 Work place inspection .....</b>	<b>10</b>
<b>6.7 Understanding of hazardous locations .....</b>	<b>10</b>
<b>6.8 Specific requirements of operation .....</b>	<b>10</b>
<b>Annex A (informative) Pictograms of MEWP misuse .....</b>	<b>18</b>
<b>Bibliography .....</b>	<b>24</b>