

# ISO 9928-2:2014-10 (E)

## Cranes - Crane operating manual - Part 2: Mobile cranes

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Presentation of the manual .....</b>	<b>1</b>
<b>5</b>	<b>Contents .....</b>	<b>1</b>
<b>5.1</b>	<b>Technical data .....</b>	<b>1</b>
<b>5.2</b>	<b>General safety instructions .....</b>	<b>2</b>
<b>5.3</b>	<b>Controls, control or work stations .....</b>	<b>2</b>
<b>5.4</b>	<b>Crane information .....</b>	<b>2</b>
<b>5.5</b>	<b>Operation .....</b>	<b>3</b>
<b>5.6</b>	<b>Leaving the crane out of service .....</b>	<b>3</b>
<b>Bibliography .....</b>		<b>4</b>