

# ISO 3600:2015-07 (E)

## Tractors, machinery for agriculture and forestry, powered lawn and garden equipment - Operator's manuals - Content and format

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Content of operator's manuals .....</b>	<b>1</b>
<b>4.1</b>	<b>Basic information .....</b>	<b>1</b>
<b>4.1.1</b>	<b>General .....</b>	<b>1</b>
<b>4.1.2</b>	<b>Identification of manual .....</b>	<b>1</b>
<b>4.1.3</b>	<b>.....</b>	<b>2</b>
<b>4.1.4</b>	<b>Identification of machine .....</b>	<b>2</b>
<b>4.1.5</b>	<b>Introduction .....</b>	<b>2</b>
<b>4.1.6</b>	<b>Safety information .....</b>	<b>2</b>
<b>4.1.7</b>	<b>Operation .....</b>	<b>3</b>
<b>4.1.8</b>	<b>Routine maintenance and adjustments .....</b>	<b>4</b>
<b>4.1.9</b>	<b>Specifications .....</b>	<b>4</b>
<b>4.2</b>	<b>Auxiliary information .....</b>	<b>5</b>
<b>4.2.1</b>	<b>General .....</b>	<b>5</b>
<b>4.2.2</b>	<b>Reception, assembly and initial set-up, and transportation .....</b>	<b>5</b>
<b>4.2.3</b>	<b>Warranty .....</b>	<b>5</b>
<b>4.2.4</b>	<b>Accessories and attachments .....</b>	<b>5</b>
<b>4.2.5</b>	<b>Parts list .....</b>	<b>5</b>
	<b>Annex A (informative) Format of operator's manuals .....</b>	<b>6</b>
	<b>Bibliography .....</b>	<b>9</b>