

ISO 11525-2:2015-10 (E)

Rough-terrain trucks - User requirements - Part 2: Slewing variable-reach trucks

| Contents | | Page |
|--------------------|---|-------------|
| Foreword | | iv |
| Introduction | | v |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms and definitions | 1 |
| 4 | General safety requirements | 3 |
| 4.1 | Principles | 3 |
| 4.2 | Operator's manual | 3 |
| 4.3 | Modifications or alterations | 3 |
| 4.4 | Manufacturer's bulletins | 4 |
| 4.5 | Operator qualifications | 4 |
| 4.6 | Operator's responsibility for training | 4 |
| 4.7 | Operator training | 4 |
| 4.7.1 | Operator training programme | 4 |
| 4.7.2 | Testing, retraining and enforcement | 6 |
| 4.8 | Inspection and maintenance | 8 |
| 4.8.1 | General | 8 |
| 4.8.2 | Preparation for inspection or repair | 8 |
| 4.8.3 | Performance checks | 8 |
| 4.8.4 | Inspection and maintenance precautions | 9 |
| 4.8.5 | Inspection and maintenance requirements | 9 |
| 4.9 | Hazardous environments | 10 |
| 5 | Operating safety rules and precautions | 10 |
| 5.1 | Operator's responsibility for safety | 10 |
| 5.2 | Visual inspection and functional tests | 11 |
| 5.3 | General operating instructions | 12 |
| 5.4 | Travelling | 13 |
| 5.5 | Picking and placing loads | 14 |
| 5.6 | Using attachments | 15 |
| Bibliography | | 17 |