

ISO 13031:2016-05 (E)

Earth-moving machinery - Quick couplers - Safety

| Contents | | Page |
|--------------------|--|-------------|
| Foreword | | iv |
| Introduction | | v |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms and definitions | 1 |
| 4 | Safety requirements and protective measures | 5 |
| 4.1 | Quick coupler | 5 |
| 4.1.1 | General | 5 |
| 4.1.2 | Engagement system | 6 |
| 4.1.3 | Locking system | 6 |
| 4.2 | Object handling | 7 |
| 4.3 | Controls | 7 |
| 4.3.1 | General requirements | 7 |
| 4.3.2 | Separate control | 7 |
| 4.3.3 | Integrated controls | 8 |
| 4.4 | Electrical circuits | 10 |
| 4.4.1 | Over-current protective devices | 10 |
| 4.5 | Pressurized systems | 10 |
| 5 | Information for use | 10 |
| 5.1 | Safety labels | 10 |
| 5.2 | Instructions and information for use | 10 |
| 5.2.1 | Operator's manual | 10 |
| 5.2.2 | Installation manual | 11 |
| 5.3 | Quick coupler marking | 11 |
| Bibliography | | 12 |