

DIN EN 707:2019-12 (E)

Agricultural machinery - Slurry tankers - Safety

Contents		Page
European foreword		3
Introduction		4
1	Scope	5
2	Normative references	5
3	Terms and definitions	6
4	Safety requirements and/or measures	6
4.1	General	6
4.2	Requirements for all types of slurry tankers	7
4.2.1	Manual controls	7
4.2.2	Tank	9
4.2.3	Spreading or injecting boom	12
4.2.4	Means of access and place to stand	13
4.2.5	Hydraulic, pneumatic and electrical interconnections	13
4.2.6	Stability and immobilisation of the tanker	13
4.2.7	Jacking points	14
4.2.8	Protection against risks associated with overhead power lines	14
4.2.9	Controlled drainage of residuals from auxiliary devices	15
4.2.10	Performance levels	15
4.3	Requirements for mechanically powered slurry tankers	15
4.4	Requirements for pneumatically powered slurry tankers	15
4.4.1	Covers for openings	15
4.4.2	Pressure gauge	16
4.4.3	Safety valve	16
4.4.4	Pneumatically powered slurry tankers with filling accelerator	16
5	Verification of the safety requirements and/or measures	16
6	Information for use	17
6.1	Instruction handbook	17
6.1.1	General	17
6.2	Markings	20
6.2.1	General	20
6.2.2	Warnings	21
Annex A (normative) List of hazards		23
Annex B (informative) Examples of slurry tankers		30
Annex ZA (informative) Relationship between this European Standard and the requirements of Directive 2006/42/EC aimed to be covered		34