

### Contents

	Foreword
	Introduction
1	Scope
2	Normative references
3	Terms and definitions
4	Technical requirements
4.1	General
4.2	Address configuration capabilities
4.2.1	General
4.2.2	Non-configurable address
4.2.3	Self-configurable address
4.2.4	Service-configurable address
4.2.5	Command-configurable address
4.3	NAME and address requirements
4.3.1	General
4.3.2	NAME
4.3.3	Address
4.3.3.1	General
4.3.3.2	Preferred address
4.3.3.3	Self-configurable address
4.3.3.4	Initial address
4.3.3.5	NULL address
4.3.3.6	Global address
4.4	Network-management procedures
4.4.1	General
4.4.2	Address-management messages and procedures
4.4.2.1	Address-management-message functions
4.4.2.2	Request-for-address-claimed message
4.4.2.3	Address-claimed message
4.4.2.4	Cannot-claim-source-address message
4.4.2.5	Commanded-address message
4.4.3	NAME management message and procedures
4.4.3.1	General
4.4.3.2	NAME management (NM) message
4.4.3.3	NAME management (NM) message parameters
4.4.3.3.1	NAME checksum/Error code
4.4.3.3.2	Qualifier flags
4.4.3.3.3	NM Control Mode Indicator
4.4.3.3.3.1	General
4.4.3.3.3.2	Mode 0 — Set Pending NAME
4.4.3.3.3.3	Mode 1 — Pending NAME
4.4.3.3.3.4	Mode 2 — Current NAME
4.4.3.3.3.5	Mode 3 — NAME ACK
4.4.3.3.3.6	Mode 4 — NAME NACK
4.4.3.3.3.7	Mode 5 — Request pending NAME
4.4.3.3.3.8	Mode 6 — Request current NAME
4.4.3.3.3.9	Mode 7 — Adopt pending NAME
4.4.3.3.3.10	Mode 8 — Request NAME address claim

- 4.4.3.3.3.11 Modes 9-15 — Reserved for future use
- 4.4.3.3.4 Commanded parameters
  - 4.4.3.3.4.1 General
  - 4.4.3.3.4.2 Commanded manufacturer code
  - 4.4.3.3.4.3 Commanded function instance
  - 4.4.3.3.4.4 Commanded ECU instance
  - 4.4.3.3.4.5 Commanded function
  - 4.4.3.3.4.6 Commanded device class
  - 4.4.3.3.4.7 Commanded self-configurable address capable
  - 4.4.3.3.4.8 Commanded industry group
  - 4.4.3.3.4.9 Commanded device class instance
- 4.4.3.4 NAME management procedures
  - 4.4.3.4.1 NAME management message support
  - 4.4.3.4.2 Set pending NAME
  - 4.4.3.4.3 Adopt Pending NAME
  - 4.4.3.4.4 Verifying NAME Source Address
  - 4.4.3.4.5 Rules for use of the NM message
- 4.4.4 Network-error management
  - 4.4.4.1 General
  - 4.4.4.2 Unable to claim address
  - 4.4.4.3 Address violation
- 4.5 Network initialization
  - 4.5.1 Acquisition of a unique address
  - 4.5.2 Address claim requirements
  - 4.5.3 Other basic requirements for initialization
  - 4.5.4 Message sequences
    - 4.5.4.1 Initialization without contention
    - 4.5.4.2 Address-claim prioritization
    - 4.5.4.3 Identical identifiers
  - 4.5.5 CF unable to obtain an address

**Annex A (informative) Examples of NAME construction**

- A.1 ECU serving the engine of a single-engined tractor
- A.2 Non-self-configurable ECU serving the ABS system of the first trailer of an on-highway, heavy-duty tractor
- A.3 Two agricultural planters connected in a system with separate row guidance on eight individual rows, each of two ECUs
- A.4 Address-to-NAME association table

Page count: 30