

DIN EN 12999:2020-06 (E)

Cranes - Loader cranes

| Contents | | Page |
|-------------------------|--|------|
| European foreword | | 5 |
| Introduction | | 6 |
| 1 | Scope | 7 |
| 2 | Normative references | 7 |
| 3 | Terms, definitions and terminology | 9 |
| 3.1 | Terms and definitions | 9 |
| 3.2 | Terminology | 13 |
| 4 | List of significant hazards | 15 |
| 5 | Safety requirements and/or safety measures | 18 |
| 5.1 | General | 18 |
| 5.2 | Structural calculation | 19 |
| 5.2.1 | Information to be given in the calculation | 19 |
| 5.2.2 | Dynamic factors | 19 |
| 5.2.3 | Loads and forces | 21 |
| 5.2.4 | Load combinations | 23 |
| 5.3 | Stress analysis | 24 |
| 5.4 | Mechanical arrangements | 25 |
| 5.4.1 | Stabilizers | 25 |
| 5.4.2 | Manual boom extensions | 26 |
| 5.4.3 | Securing for transport | 26 |
| 5.4.4 | Hoists | 26 |
| 5.4.5 | Load hooks | 26 |
| 5.5 | Hydraulic system | 27 |
| 5.5.1 | General | 27 |
| 5.5.2 | Pump | 27 |
| 5.5.3 | Hydraulic reservoir | 27 |
| 5.5.4 | Pressure limiting device | 27 |
| 5.5.5 | Hoses, tubes and fittings | 27 |
| 5.5.6 | Precautions against hydraulic line rupture | 28 |
| 5.5.7 | Sink rate for boom system | 28 |
| 5.5.8 | Slewing mechanism | 29 |
| 5.6 | Limiting and indicating devices | 29 |
| 5.6.1 | General | 29 |
| 5.6.2 | Rated capacity limiter | 30 |
| 5.6.3 | Lowering facility | 31 |
| 5.6.4 | Rated capacity indicators | 31 |
| 5.6.5 | Limiters | 31 |
| 5.6.6 | Operational warning | 31 |
| 5.6.7 | Acoustic warning | 32 |
| 5.6.8 | Stopping device | 32 |
| 5.7 | Controls | 32 |
| 5.7.1 | General | 32 |
| 5.7.2 | Symbols | 32 |
| 5.7.3 | Layout of bi-directional controls | 33 |
| 5.7.4 | Guidance for high seat controls | 33 |
| 5.8 | Control stations | 33 |

| | | |
|--------|---|----|
| 5.8.1 | General | 33 |
| 5.8.2 | Raised control stations | 35 |
| 5.9 | Electrical systems | 36 |
| 5.9.1 | General | 36 |
| 5.9.2 | Electromagnetic compatibility | 36 |
| 5.10 | Installation | 36 |
| 5.10.1 | General | 36 |
| 5.10.2 | Mounting | 36 |
| 5.10.3 | Stability | 37 |
| 5.10.4 | Noise | 37 |
| 5.10.5 | Vibrations | 38 |
| 5.10.6 | Electrical systems (installation) | 38 |
| 5.10.7 | Hydraulic components | 38 |
| 5.10.8 | Access | 38 |
| 6 | Verification of the safety requirements and/or measures | 38 |
| 6.1 | General | 38 |
| 6.2 | Testing and test procedures | 42 |
| 6.2.1 | General | 42 |
| 6.2.2 | Functional test | 42 |
| 6.2.3 | Static test | 42 |
| 6.2.4 | Dynamic test | 43 |
| 6.2.5 | Stability test | 43 |
| 6.2.6 | Test documentation | 45 |
| 6.2.7 | #Documentation for variable stabilizer deployment | 45 |
| 6.3 | Noise emission measurement | 45 |
| 7 | Information for use | 46 |
| 7.1 | General | 46 |
| 7.2 | Manuals | 46 |
| 7.2.1 | Provision of manuals | 46 |
| 7.2.2 | Instructions for the installer | 46 |
| 7.2.3 | Operator's manual | 46 |
| 7.2.4 | Maintenance manual | 48 |
| 7.3 | Marking | 48 |
| 7.3.1 | General | 48 |
| 7.3.2 | Manufacturer's plate | 48 |
| 7.3.3 | Installer's plate | 49 |
| 7.3.4 | Load signs | 49 |
| 7.3.5 | Special signs on timber handling cranes | 53 |
| 7.3.6 | Marking of slewing centre | 54 |
| 7.3.7 | #Marking of maximum ground load | 54 |
| 7.3.8 | Marking for high seat | 54 |
| | Annex A (informative) Examples of configurations and mountings | 55 |
| A.1 | Boom systems | 55 |
| A.1.1 | Loader cranes with straight boom system | 55 |
| A.1.2 | Loader cranes with articulated boom system | 55 |
| A.2 | Examples of loader crane mountings | 56 |
| | Annex B(informative) Stress history parameter s and stress history classes S | 60 |
| | Annex C(informative) Explanatory notes | 64 |
| C.1 | Rated capacity limiters | 64 |
| C.2 | Timber handling cranes - Line rupture | 64 |
| C.3 | Control stations | 64 |
| | Annex D(informative) Examples of dangerous movements | 65 |
| | Annex E(normative) Symbols for working and setting-up functions | 67 |

| | |
|--|-----------|
| Annex F(informative) Control system - Preferred vertical layout for controls operated from the ground | 69 |
| Annex G(informative) Control system - Horizontal layout order | 71 |
| Annex H(informative) Control levers for high seats and remote controls | 74 |
| H.1 High seat controls | 74 |
| H.1.1 Multidirectional (joy-stick) controls | 74 |
| H.1.2 Bi-directional controls | 74 |
| H.2 Remote controls | 74 |
| Annex I (not used) | 77 |
| Annex J(normative) Cabins fitted on vehicle mounted loader cranes up to a net lifting moment of 250 kNm | 78 |
| Annex K(informative) Examples of raised control stations | 81 |
| Annex L(normative) Raised control stations - Measures regarding hand rails and hand holds, ladders and steps | 83 |
| Annex M(informative) Installation of a loader crane on a vehicle | 86 |
| M.1 General | 86 |
| M.2 Installation: minimum data | 86 |
| M.2.1 Crane dimensions in transport position: data | 86 |
| M.2.2 Crane data (see Figure M.2) | 87 |
| M.2.3 Mounting data | 87 |
| M.2.4 Power requirements | 87 |
| M.2.5 Stability calculations: data | 87 |
| M.3 Power take off (PTO) and pump displacement | 88 |
| M.4 Calculation method for determination of sub-frame dimensions | 88 |
| M.4.1 General considerations | 88 |
| M.4.2 Stresses | 89 |
| M.4.3 Material and limit states | 89 |
| M.4.4 Symbols and equations | 89 |
| Annex N(informative) Selection of a suitable set of crane standards for a given application | 92 |
| Annex ZA(informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC | 94 |
| Bibliography | 95 |