

# ISO 6750-1:2019-10 (E)

## Earth-moving machinery - Operator's manual - Part 1: Contents and format

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
1	Scope .....	1
2	Normative references .....	1
3	Terms and definitions .....	1
4	General information for operator's manuals .....	4
4.1	General information .....	4
4.2	Machine configurations .....	4
4.3	Attachments, tools, additional equipment .....	5
4.4	Units of measurement .....	5
4.5	Original language and translations .....	5
4.6	Graphical symbols .....	5
4.7	Meaning of audible and visual signals on the machine .....	5
4.8	Basic information .....	5
5	Content of operator's manuals .....	5
5.1	General .....	5
5.2	Identification of the operator's manual .....	5
5.3	Table of contents .....	6
5.4	Identification of the machine .....	6
5.5	Introduction .....	7
5.6	Safety information .....	8
5.6.1	Residual risks .....	8
5.6.2	Safety alert symbol .....	8
5.6.3	Signal words .....	8
5.6.4	Safety messages .....	8
5.6.5	Machine safety labels .....	9
5.7	Operation .....	11
5.7.1	General .....	11
5.7.2	Controls and displays .....	11
5.7.3	Operating instructions .....	11
5.8	Troubleshooting .....	11
5.9	Maintenance and adjustments .....	12
5.9.1	General .....	12
5.9.2	Precautions prior to maintenance .....	12
5.9.3	Maintenance instructions for the operator .....	12
5.10	Spare parts list .....	13
5.11	Preservation and storage .....	13
5.11.1	General .....	13
5.11.2	Prior to long-term storage .....	13
5.11.3	After long-term storage .....	13
5.12	End of service life information .....	13
5.13	Specifications -- Machine technical data .....	14
Annex A (normative)	Basic information for inclusion in operator's manual .....	15
Annex B (informative)	Presentation and format of the operator's manual -- Recommendations .....	18
Annex C (informative)	Electronic media .....	21
Bibliography .....		23