ISO 6750-1:2019-10 (E)

Earth-moving machinery - Operator's manual - Part 1: Contents and format

Contents

Page

Foreword iv

Introduction v

1 Scope 1

2 Normative references 1

3 Termsanddefinitions 1

4 General information for operator's manuals 4
4.1 General information 4
4.2 Machine configurations 4
4.3 Attachments, tools, additional equipment 5
4.4 Units of measurement 5
4.5 Original language and translations 5
4.6 Graphical symbols 5
4.7 Meaning of audible and visual signals on the machine 5
4.8 Basic information 5

5 Content of operator's manuals 5
5.1 General 5
5.2 Identification of the operator's manual 5
5.3 Table of contents 6
5.4 Identification of the machine 6
5.5 Introduction 7
5.6 Safety information 8
5.6.1 Residual risks 8
5.6.2 Safety alert symbol 8
5.6.3 Signal words 8
5.6.4 Safety messages 8
5.6.5 Machine safety labels 9
5.7 Operation 11
5.7.1 General 11
5.7.2 Controls and displays 11
5.7.3 Operating instructions 11
5.8 Troubleshooting 11
5.9 Maintenance and adjustments 12
5.9.1 General 12
5.9.2 Precautions prior to maintenance 12
5.9.3 Maintenance instructions for the operator 12
5.10 Spare parts list 13
5.11 Preservation and storage 13
5.11.1 General 13
5.11.2 Prior to long-term storage 13
5.11.3 After long-term storage 13
5.12 End of service life information 13
5.13 Specifications -- Machine technical data 14

Annex A (normative) Basic information for inclusion in operator's manual 15

Annex B (informative) Presentation and format of the operator's manual -- Recommendations 18

Annex C (informative) Electronic media 21

Bibliography 23