

ISO 11525-1:2020-01 (E)

Rough-terrain trucks - Safe use requirements - Part 1: Variable-reach trucks

Contents		Page
Foreword		iv
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
4	General requirements	2
4.1	Principles	2
4.2	Operator's manual(s)	3
4.3	Modifications or alterations	3
4.4	Manufacturer's bulletins	3
4.5	Operator qualifications and training	4
4.6	Inspection and maintenance	4
4.6.1	General	4
4.6.2	Preparation for inspection or repair	4
4.6.3	Performance checks	4
4.6.4	Inspection and maintenance precautions	5
4.6.5	Inspection and maintenance requirements	6
4.7	Hazardous environments	6
4.8	Refuelling	7
5	Operating safety rules and precautions	7
5.1	Operator's responsibility for safety	7
5.2	Visual inspection and functional tests	7
5.3	General operating instructions	8
5.4	Travelling	10
5.5	Picking and placing loads	11
5.6	Using attachments	12
Bibliography		13