

Contents

- Foreword
- Introduction
- 1 Scope
- 2 Normative references
- 3 Terms and definitions
- 4 Test set-up procedure
 - 4.1 General
 - 4.2 Radiated and conducted radio-frequency emissions
 - 4.3 Voltage fluctuation and flicker
 - 4.4 Mains supply harmonics
- 5 Applicability of tests
- 6 Emission limits
 - 6.1 Enclosure ports (radiative)
 - 6.2 A.C. mains ports (conductive)
 - 6.3 Output power ports (conductive)
 - 6.4 Impulse noise
 - 6.5 Voltage fluctuations
 - 6.6 Mains supply current harmonics
 - 6.7 Measurement
 - 6.7.1 Radiated and conducted radio-frequency emission
 - 6.7.2 Mains supply harmonics
- 7 Documentation for the installer of the apparatus/assembly of apparatus

Page count: 13