

DIN EN 17076:2021-06 (E)

Tower cranes - Anti-collision systems - Safety requirements

Contents	Page
European foreword	3
Introduction	4
1 Scope	5
2 Normative references	5
3 Terms and definitions	6
4 List of significant hazards	12
5 Technical requirements	14
5.1 General	14
5.2 Information requested to operate the anticollision device and system	15
5.3 Requirements for controls of anticollision devices	17
5.4 Additional requirements	17
6 Operation of the anticollision device	18
6.1 Startup sequence	18
6.2 Normal operation mode of an anticollision device	18
6.3 Defective status of an anticollision device	19
6.4 Anticollision device in a free jib slewing mode	20
6.5 Anticollision device in overriding mode	20
6.6 Setting mode of an anticollision device	21
6.7 Communication between anticollision devices	21
6.8 Indicators at the control station	21
6.9 Outside indicators	21
7 Verification of the safety requirements and/or protective measures	21
8 Marking	23
9 Information for use	23
9.1 General	23
9.2 Instructions for installation	23
9.3 Instructions for setting and functional tests	24
9.4 Instructions for use	24
Annex A(informative) Selection of a suitable set of crane standards for a given application	25
Annex ZA(informative) Relationship between this European Standard and the essential requirements of Directive 2006/42/EC aimed to be covered	27
Bibliography	29