

DIN EN 474-11:2023-02 (E)

Earth-moving machinery - Safety - Part 11: Requirements for earth- and landfill compactors

Contents		Page
European foreword		3
Introduction		5
1	Scope	6
2	Normative references	6
3	Terms and definitions	7
4	Safety requirements and/or protective/risk reduction measures	7
4.1	General	7
4.2	Operator's station	8
4.3	Seat	8
4.4	Steering system	9
4.5	Braking system	9
4.6	Stability	9
4.7	Lifting operation	9
4.8	Protective measures and devices	9
5	Verification of the safety requirements and/or protective/risk reduction measures	9
6	Information for use	10
6.1	General	10
6.2	Machine safety labels	10
6.3	Operator's manual	11
Annex A (informative) List of significant hazards		12
Annex B (normative) Braking requirements for earth- and landfill compactors		17
B.1	Terms and definitions	17
B.2	General requirements	17
B.3	Test conditions	17
B.4	Performance test	19
Annex C (informative) Illustrations		21
Annex ZA (informative) Relationship between this European Standard and the essential requirements of Directive 2006/42/EC machinery, and amending Directive 95/16/EC (recast) [2006 L157] aimed to be covered		22
Bibliography		27